





# DIGITAL PIANO



**Owner's Manual** 













### INFORMATION FOR YOUR SAFETY!

#### THE FCC REGULATION WARNING (for USA)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Unauthorized changes or modification to this system can void the user's authority to operate this equipment.

#### **CAUTION**

The normal function of the product may be disturbed by Strong Electro Magnetic Interference. If so, simply reset the product to resume normal operation by following the owner's manual. In case the function could not resume. please use the product in other location.

#### **PRECAUTIONS**

#### PLEASE READ CAREFULLY BEFORE PROCEEDING

Please keep this manual in a safe place for future reference.

#### **Power Supply**

When removing the electric plug from an outlet, always hold the plug itself and not the cord.

Do not connect the instrument to an electrical outlet using a multiple-connector or an AC outlet of voltage other than that for which your instrument is intended.

Remove the electric plug from the outlet when the instrument is not to be used for extended periods of time, or during electrical storms.

#### Connections

Before connecting the instrument to other devices, turn off the power to all units. This will help prevent malfunction and / or damage to other devices.

#### Location

Do not expose the instrument to the following conditions to avoid deformation, discoloration, or more serious damage:

- Direct sunlight
- Extreme temperature or humidity
- · Excessive dusty or dirty location
- · Strong vibrations or shocks
- · Close to magnetic fields

#### Interference with other electrical devices

Radios and televisions placed nearby may experience reception interference. Operate this unit at a suitable distance from radios and televisions.

#### Cleaning

Clean only with a soft, dry cloth.

Do not use paint thinners, solvents, cleaning fluids, or chemical-impregnated wiping cloths.

#### Handling

Do not apply excessive force to the switches or controls. Do not let paper, metallic, or other objects get into the instrument. If this happens, remove the electric plug from the outlet. Then have the instrument inspected by qualified service personnel.

Disconnect all cables before moving the instrument.















# Contents

Panel & Display Description	
Front Panel	4
LCD Display	4
Rear Panel	5
Setup	
Setup Guide	6
Connections	_
Power Jack	
Connecting a pair of Headphones	
Connecting an Audio Equipment	
Connecting an MP3/CD Player	
Connecting a Computer	10
Adjusting the Master Volume	11
A 11 (2 (4 A 17 ) B 111	
Adjusting the Voice Brilliance	11
Playing the Demo Song	11
Playing the Demo Song	11
Playing Voices	
Playing Voices	12
Playing two voices simultaneously-DUAL	
Playing Different Voices with Both hands-LOWER	
, ,	
Twinova	13
Auto Accompaniment	
Play Auto Accompaniment(rhythm track only)	
Play Auto Accompaniment(all tracks)	
Accompaniment Sections	
Playing Different Accompaniment Sections	
Accompaniment Volume	
Chord Fingering	
Tempo	
One Touch Setting  Metronome	
Wett offorme	10
Mixer	17
Other Functions	
Tune	18
Transpose	18
Split Point	19
Beat Type	19
Beat Volume	
Harmony Switch	
Harmony Type	
Scale Switch	
Soolo Typo	
Scale Type	20
Scale Root	20 20

DSP Effect	21
Reverb Type	
Reverb Level	
Chorus Type	
Chorus Level	
MIDI IN	
MIDI OUT	
Touch	
Language	
PowerOff	23
Desired Marine	
Register Memory	
Registering the Panel Setting	
Recalling the Registered Panel Settings	
Selecting a Registration Bank	23
Song Recording	
Start Recording	24
Stop Recording	
Playback Recording	
Delete User Song	
Delete Oser Sorig	20
Song	
Listening to the songs	26
Song Control	
Practice the song	
Restore Factory Setting	26
Restore Factory Setting	26
Connecting USB Flash Drive	
Connecting USB Flash Drive USB Flash Drive Operation	27
Connecting USB Flash Drive USB Flash Drive Operation	27
Connecting USB Flash Drive USB Flash Drive Operation	27 27
Connecting USB Flash Drive USB Flash Drive Operation	27 27 28
Connecting USB Flash Drive USB Flash Drive Operation	27 28 28
Connecting USB Flash Drive USB Flash Drive Operation	27 28 28 29
Connecting USB Flash Drive USB Flash Drive Operation	27 28 28 29
Connecting USB Flash Drive USB Flash Drive Operation	27 28 28 29
Connecting USB Flash Drive USB Flash Drive Operation	27 28 28 29 29
Connecting USB Flash Drive USB Flash Drive Operation	27282929
Connecting USB Flash Drive USB Flash Drive Operation	27282929
Connecting USB Flash Drive USB Flash Drive Operation	2728292930
Connecting USB Flash Drive USB Flash Drive Operation	2728292930
Connecting USB Flash Drive USB Flash Drive Operation	272829293031
Connecting USB Flash Drive USB Flash Drive Operation	272829293031
Connecting USB Flash Drive USB Flash Drive Operation	272829293031
Connecting USB Flash Drive USB Flash Drive Operation	272829293031
Connecting USB Flash Drive USB Flash Drive Operation	272829303131
Connecting USB Flash Drive USB Flash Drive Operation	272829303131
Connecting USB Flash Drive USB Flash Drive Operation	27282930313131
Connecting USB Flash Drive USB Flash Drive Operation	2728293031313131
Connecting USB Flash Drive USB Flash Drive Operation	272829303131313131










### **Panel & Display Description**

#### **Front Panel**



- 1. [VOLUME] Knob Adjust master volume
- 2. [BRILLIANCE] Knob Adjust voice brilliance
- 3. USB device socket Insert a USB flash drive
- 12. [FILL C] button A Fill-in C plays
- 13. [FILL D] button A Fill-in D plays
- 14. [ACC VOL] button Adjust ACCOMP volume
- 15. [TEMPO+/-] button Adjust the current tempo
- 17. A.B.C. MODE lamp Indicate A.B.C. mode status: on or off
- 18. FULL RANGE MODE lamp Show if the full range mode is on or off
- 19. LCD Show all the parameters related to the current operation.

#### When [SHIFT] key pressed

- 4. Style button Enter the style mode
- When [SHIFT] key released 4. Style direct button
- Select a direct style 5. [FUNCTION+/-] button

Enter function menu

- 6. [MIXER] button
- Enter mixer menu


#### **SONG MODE:**

song

- 7. [START/STOP] button Start or stop playing the song
- 8. [PAUSE] button Pause or resume playing the
- 9. [REPEAT A/B] button Set the beginning and the
- end for a loop section of a selected song
- 10. [REW] button Rewind the song
- 11. [FF] button Fast forward the song
- 16. [MELODY OFF L/R] button Use to mute/activate left or right-hand part, allowing each part to be practiced separately

#### STYLE MODE:

- 7. [START/STOP] button Start or stop playing the style
- 8. [SYNC START] button Turn the Sync Start on and off
- 9. [INTRO/ENDING] button Play the Intro or Ending
- 10. [FILL A] button A Fill-in A plays
- 11. [FILL B] button A Fill-in B plays
- 16. [CHORD MODE] button Enter the chord mode



### LCD

- 1. Chord display area Display chord information.
- 2. Instant message area Display the current tempo, measure, memory/O.T.S setting.
- 3. Status display area Display the status of function, USB drive, USB, etc.
- 4. System message display area Display important messages related to the current operation. I.e. in voice mode, it displays the voice name and number.
















#### **Panel & Display Description**



#### 20. [USB DEVICE] button

Enter USB DEVICE menu

#### 22. Data dial

Increase and decrease the value

#### 23. [+/YES] button

Increase the value

#### 24. [-/NO] button

Decrease the value

#### 26. [DUAL] button

Turn the Voice R2 on and off

#### 27. [LOWER] button

Turn the Voice L1 on and off

#### 28. [TWINOVA] button

Turn the TWINOVA on and off

#### 29. [OCTAVE] button

Set octave in TWINOVA mode

#### 30. [METRO] button

Turn the metronome on and off

#### When [SHIFT] key pressed

#### 21. [DEMO] button

Enter demo mode and play demo songs

#### 25. [VOICE] button

Enter the voice mode

#### 32. [RECORD] button

Enter record mode

#### 33. [ACCOMP] button

Select the accompaniment track to record

#### 34~38. MELODY 1-5 button

Select the melody track 1-5 to record

#### When [SHIFT] key released

#### 21. [SONG] button

Enter song mode and play songs

#### 25. Voice direct button

Select a direct voice

#### 32. [BANK] button

Select a bank to store settings

#### 33. [STORE] button

Register the current panel settings

#### 34~37.M1~M4 button

Recall the registered panel settings

#### 38. [O.T.S] button


Turn One Touch Setting on and off

#### 31. [SHIFT] button

Press and hold it to access

secondary functions of other buttons

#### **Rear Panel**



#### 39. POWER SWITCH

Turn the power on and off

#### **40. PHONE 1 / PHONE 2**


Please refer to Connecting a pair of Headphones

#### 41. USB JACK

Connect to a computer

#### 42. AUX IN Jack

Connect an external sound source, such as an MP3 or CD player



#### 43. AUX OUT Jack

Connect the audio equipment

#### 44. DC IN Jack

Connect DC power adaptor


#### 45. SPEAKER Jack

Connect the loudspeaker

#### 46. PEDAL Jack

Connect the unit pedal

#### **Pedal**



#### 47. Soft Pedal

When you step on the soft pedal, all notes played on the keyboard will have a softer effect.

#### 48. Sostenuto Pedal

When you step on the sostenuto pedal, the notes played before you step on the pedal would have a sustain effect.

#### 49. Sustain Pedal

When you step on the sustain pedal, all notes played on the keyboard will have a longer sustain


















### Setup

This section contains information about setting up your instrument before playing. Please go through this section carefully before turning the power on.

#### **Setup Guide**

Before you proceeding to assemble the stand, get a Philips screwdriver (not supplied).

Make sure you have the following parts, which are supplied in the package.











### Setup


A. Install the piano legs as shown below.

First, insert the four Turned Nuts into the holes at the back of the Pedal Panel.


Second, align both the left and the right legs to each side of the Pedal Panel.

Third, insert the screws M6 x 50 through the screw holes and fit them into the Turned Nuts. Finally, tighten with a screwdriver and place the plastic caps on top.

(Check the components in the right direction before installing.)



B. As shown below, Place the piano body on the stand, fix it with four hand screws.




C. Install the Sound Boxes as shown below. First, place the sound boxes as shown.

Second, insert the screws M6x50 through holes on the legs and fit them into the sound box. Tighten with a screwdriver and place the plastic caps on top.

Third, insert the screws M4x15 through the sound boxes and fit them into the holes at the bottom of The Piano.

Tighten with a screwdriver. Finally, insert the sound box



















### Setup

**D.** Insert the pedal cord to the Pedal jack at the rear of The Piano and fix the cord to the sound boxes with a cable tie.




**E.** Fix the back board to the sound box cover (left and right) with gasket and screw  $\phi 4*30$ .



**F.** Connect the power cord to the DC IN jack at the rear of The Piano, and then plug it to an AC outlet. The installation is completed now.

Turn on the power and enjoy the perfect performance.



















## **Connections**

#### **Power Jack**

#### **Power Supply**

- 1. Make sure that the piano is turned off. Before you switch the piano on or off, turn down the volume of piano and any connected audio equipments first.
- 2. Connect the AC adaptor to the power supply jack of this piano.
- 3. Plug the AC adaptor into an AC outlet.
- 4. Press the [POWER] button, the LCD will display "LOADING...", Which indicates the piano is powered on.
- 5. If you are ready to turn off the piano, press the [POWER] button again.

#### Notes:

- 1. The piano will automatically shut down in about 30 minutes if it is not used.
- 2. When the keyboard is not in use or during thunderstorm, please disconnect the power for safety purpose

#### **Connecting a pair of Headphones**

A standard pair of stereo headphones can be plugged in here for private practice or late-night playing.

Phones1: when a pair of headphones is plugged into the jack 1, the internal stereo speaker system is automatically shut off. The sound can only be heard from headphones.

Phones2: when a pair of headphones is plugged into the jack 2, the sound can be heard from both headphones and speakers of the instrument.

#### Note:

To avoid the risk of hearing loss, do not listen with headphones at high volume level for a long period of time.

#### Connecting an Audio Equipment


The rear-panel AUX.OUT jack delivers the output of the instrument to a keyboard amplifier, a mixing console, or tape recorder. Use an audio cord to connect the AUX OUT jack on the rear panel to the AUX IN jack of the amplifier.


#### Note:


To avoid damaging the speakers, set the volume level to minimum before connecting the power and other devices.

#### Connecting an MP3/CD Player

Connect the audio output of an MP3/CD player or other audio source to the stereo AUX.IN jack on the rear panel. The input signal is mixed with the piano signal, allowing you to play along.






















#### **Connections**

**Connecting a Computer**You can use the USB jack to receive MIDI messages from computer or transmit MIDI messages to computer.

#### Note:

Do not set the USB device to be input and output simultaneously when setting the software on PC. Otherwise the sound will be overlapped when playing the keyboard.

















## **Adjusting the Master Volume**

Rotate the [VOLUME] knob to right, the volume increases and vice versa.



### **Adjusting the Voice Brilliance**

Rotate the [BRILLIANCE] knob to right, the voice sounds brighter and vice versa. You can change the piano brilliance as you wish.




## **Playing the Demo Song**

The instrument features 5 wonderful demos. Please refer to Demo List. 1. Holding down the [SHIFT] button, then press the [DEMO] button to

- Holding down the [SHIFT] button, then press the [DEMO] button to start the demo song playing, and the LCD will display the number and name of the demo.
- 2. Beats Flashing
  During demo playback, the LED indicator of [START/STOP] will flash
  with the current tempo, red for strong beat and green for weak beat.
- 3. You can use the data dial, [+/YES] / [-/NO]button to select a demo song.
- Holding down the [SHIFT] button, then press the [demo] button or press the [START/STOP] button directly to stop playing and exit the demo mode.

#### Note:

- In demo mode, only the following button functions will be available: [DEMO], [START/STOP], [TEMPO+/-], [+/YES], [-/NO], Data dial, [VOLUME], [BRILLIANCE], and [POWER].
   All other buttons and the keyboard function will become invalid.
- 2. In recording, style or song mode, the LED indicator of [START/STOP] will flash with the current tempo.



















### **Playing Voices**

The instrument features 600 exceptionally realistic voices. Please refer to Voices List.

#### **Playing Voices**

- 1. In standby mode, holding down the [SHIFT] button, then press one of the voice direct button to enter the voice mode. LCD will display the name and number of the current voice and highlights "R1".
- Use the data dial, [+/YES]/ [-/NO] button to select the voice you want to play. You can also use the voice direct button to select a voice
- 3. Play the keyboard and enjoy the wonderful voice.

#### Note:

When the Dual and Lower functions are on, hold down [SHIFT] button, then press one of the voice select buttons to shift the voice source between R1, R2 and L1. The selected one will be highlighted on LCD.

#### Playing two voices simultaneously-DUAL

- 1. In standby mode, press [DUAL] button to turn on dual voice. LCD displays current voice name and number, and highlights "R2".
- When "R2" is highlighted, use the data dial, the [+/YES], [-/NO] button or voice direct button to select the dual voice you want to play.
- 3. Play the keyboard, you will hear two different voices sounded simultaneously in a layer. It seems like two instruments playing at the same time.

#### Note:

When the keyboard has been split, only the right hand area will play the dual voice.

# Play Different Voices with Both hands-LOWER


- 1. In standby mode, press [LOWER] button to turn on lower voice. The keyboard is split into two independent areas, which have different voices. LCD displays the left hand voice name and number, and highlights "L1".
- 2. When "L1" is highlighted, use the data dial, the [+/YES], [-/NO] button or voice direct button to select the lower voice you want to play.
- 3. Play the keyboard with both hands, and you will hear two different voices from the two areas.

#### Note:


The right hand voice will not change when you change lower voice.

#### Split Point

The Point on the keyboard that separates voice L1 and voice R1/R2 is called the "split point". The split point is set to F#3/G3 at the factory setting. However you can set this to any key you want. Please refer to KeySplit setting for split point.





























### Twinova

The twinova mode splits the keyboard into two independent areas, which have the same pitch and voice, for the convenience of one-to-one teaching.

- 1. In standby mode, press [TWINOVA] button to turn on twinova. LCD highlights "TWINOA". In twinova mode, dual voice and lower voice are unavailable. The default split point is E3 (32). Press [TWINOVA] button again you can exit twinova.
- In twinova mode, the default voice of right hand and left hand is the upper voice you select before entering twinova mode. Use the data dial, the [+/YES], [-/NO] button or the voice direct button to select a voice
- 3. In twinova mode, press [OCTAVE] button, LCD temporarily displays the octave value of twinova. Now you can use the data dial, the [+/YES], [-/NO] button to set octave value of twinova. The range of octave is -1 to 1.

#### Note:

- 1. During song playback, the twinova is invalid.
- 2. Please refer to Split Point setting to set the split point.



### **Auto Accompaniment**

The auto accompaniment feature puts a full backing band at your fingertips. To use it, all you have to do is to play the chords with your left hand using your selected accompaniment style, and then the accompaniment will automatically play along, instantly following the chords you play. With auto accompaniment, even a solo performer can enjoy playing with the backing of an entire band or orchestra. This keyboard features 240 (including 10 user styles: 231-240) styles in a variety of musical genres. Try to select some of the different styles (refer to Style List) and enjoy the auto accompaniment.


# Play Auto Accompaniment(rhythm track only)

- In standby mode, hold down the [SHIFT] button, then press any of the style direct button to enter the style mode. LCD displays the name and number of the current style.
- 2. Use the data dial, the [+/YES], [-/NO] button or the style direct button to select a style.
- 3. Press the [START/STOP] button to start the rhythm tracks of the auto accompaniment. Also you can press [SYNC START] and then play any key to start the rhythm tracks of the auto accompaniment.

#### Play Auto Accompaniment(all tracks)

 In standby mode, press [CHORD MODE] button to enter "auto bass chord" (A.B.C.)mode. The "FINGERED" LED on the panel will light up. The keyboard is split into two areas. Play chords in the left hand area

Press [CHORD MODE] button again to enter "full range" mode. The "FULL RANGE" LED on the panel will light up. You can play chords over the entire keyboard in normal fingering.





















2. Press [SYNC START] button, and then play a chord in the chord area to start auto accompaniment of all tracks. When you change a chord, the accompaniment automatically changes.

Alternatively, press [START/STOP] button to start auto accompaniment of rhythm track, then play a chord in the chord area. It will start auto accompaniment of all tracks

#### **Accompaniment Sections**

There are various types of Auto Accompaniment sections that allow you to vary the arrangement of the accompaniment to match the song you are playing.

They are: Intro, Main (A,B,C,D), Fill (A, B,C,D), and Ending. By switching among them during your performance you can easily produce the dynamic elements of a professional sounding arrangement in your performance.

#### **INTRO Section**

The intro is an opening section of the song. When the intro pattern is finished, the system will automatically shift to the main section.

#### **MAIN Section**

The main is an important section of the song. And it plays an accompaniment pattern and repeat infinitely until another section's button is pressed.

#### **FILL IN Section**

Auto fill in function automatically adds a fill to your performance. When the fill-in is finished, accompaniment shifts to the Main section (A,B,C,D).

#### **ENDING Section**

Ending is used for the ending of the song. When the ending is finished, accompaniment automatically stops. The length of the ending differs depending on the selected style.

#### Note:


During style playback, hold down one of the FILL [A]-[D] buttons, and the selected fill-in pattern will play continuously until the button is released.

When style stops, press one of the FILL [A]-[D] buttons to select a main section. The corresponding LED will light up.

## Playing Different Accompaniment Sections

- 1. Press style direct button or use the data dial, [+/YES]/[-/NO] button to select a style.
- Press [CHORD MODE] button to enter A.B.C. (auto bass chord) mode.
- 3. Press [SYNC START] button.
- 4. Press [FILL A] button.
- Press the [INTRO/ENDING] button. Now "A" LED flashes on panel, the style is ready to play.
- It will start the accompaniment as soon as you start playing in Chord section. When the intro is finished, it automatically leads into Main A section.





















- 7. Press the [FILL B] / [FILLDC] / [FILL D] button. A fill-in plays, automatically followed by the Main B/C/D section.
- 8. Press the [INTRO/ENDING] again will lead it into the Ending Section. When the ending is finished, the auto accompaniment automatically stops.

#### **Accompaniment Volume**

The function will adjust the accompaniment volume, so as to keep an appropriate balance between the accompaniment volume and the voice volume.

Press [ACC VOL] button, the LCD will display ACCOMP volume. At this time, you can use the data dial, or [+/YES]/[-/NO] button to adjust accomp volume. (from 0 to 127)

#### **Chord Fingering**

How the chords are played or indicated with your left hand (in the auto accompaniment section of the keyboard) is referred to as "fingering". There are 2 types of fingerings as described below.

#### **Chord Basics**

A chord, in music, is any harmonic set of three or more notes that is heard as if sounding simultaneously. The most frequently encountered chords are triads. A triad is a set of three notes that can be stacked in thirds. When stacked in thirds, the triad's members, from lowest pitched tone to highest, are called: the Root, the Third, and the Fifth.

#### **Triad Type**

There are following basic triad types:

Major Triad	A root with a major third added above and a perfect fifth
	will consist as a "Major Triad".
Minor Triad	A root with a minor third added above and a perfect fifth
	will consist as a "Minor Triad".
Augmented	A root with a major third added above and an
Triad	augmented fifth will consist as an "Augmented Triad".
Diminished	A root with a minor third added above and a diminished
Triad	fifth will consist as a "Diminished Triad".
	fifth will consist as a "Diminished Triad".

#### **Chord Inversion**

We define this chord its root is not in the bass (i.e., is not the lowest note) as an inversion chord. When the root is in the bass, we call the chord: root-position chord. If we put the Third and Fifth in the root position, then it forms "Inversion", we call this chord "Inversion Chord". See the following major triad and its inverted chord.


#### **Chord Name**


The chord name contains two parts content: Chord root and Chord type.

#### Single Finger


Single-finger makes it simple to produce major, seventh, minor and minor seventh chords by pressing a minimum number of keys on the auto accompaniment section.









Root Position First Inversion Second Inversion























### **Auto Accompaniment**

#### Multi-finger

Multi-finger allows you to play chords in normal fingering. Try playing the 32 chord types in C scale as listed on the right.

#### Note:

In full range mode, the entire keyboard will only recognize chords played in normal fingering.

#### Tempo

Each style of the instrument has been set with a default or standard tempo, however, this can be changed by using the [TEMPO+]/ [TEMPO-] buttons.

- 1. Use the [TEMPO+] or [TEMPO-] button to change the tempo. While the tempo data is flashing, use the data dial also can change the
- 2. Press the [TEMPO+]/[TEMPO-] buttons simultaneously to restore the default tempo setting.

#### One Touch Setting

When One Touch Setting is switched on, you can instantly recall all auto accompaniment related settings including voices selection and digital effects simply with a single touch of a button.

- 1. Press the [O.T.S.] button to turn on the One Touch Setting for current style.
- 2. Press one of the one touch setting buttons [M1]-[M4]. Various panel settings (such as voice, effect, etc.) that match the selected style can be instantly recalled.

Auto accompaniment is automatically turned on during O.T.S mode.

3. Play the keyboard.

One Touch Setting parameter list:

Part ON/OFF (VOICE R1, R2, L1)

Voice Change (VOICE R1, R2, L1)

Voice Volume (VOICE R1, R2, L1)

Voice Reverb Level (VOICE R1, R2, L1)

Voice Chorus Level (VOICE R1, R2, L1)

#### Metronome

The metronome provides a steady beat to help you practise at a preset tempo.


- 1. Turn on the metronome Press the [METRO] button to turn the metronome on.
- 2. Turn off the metronome Press the [METRO] button again to turn the metronome off.
- 3. Metronome beat type setting Please refer to the Beat Type setting.


#### Note:

The metronome will respond in the next beat if it is turned on when the accompaniment is playing.


In recording, metronome beats cannot be recorded.

16





O.T.S.



















Mixer function adjusts separately the volume of different tracks.

1. Press the [MIXER] button. Enter the mixer menu. Press the [MIXER] button repeatedly to select a track to change its volume.

2. To adjust the selected volume setting, please use the data dial or the [+/YES]/[-/NO] button.

Press [+/YES] and [-/NO] button simultaneously to turn off a track

Press[+/YES]and[-/NO] button simultaneously again to turn on a track volume.

The option and parameters are as follows:

Option	LCD display		Range
Rhythm slave volume	Slave Rhythm:	XXX	0 - 127
Rhythm master volume	Master Rhythm:	XXX	0 - 127
Bass volume	Bass:	XXX	0 - 127
Chord 1 volume	Chord1:	XXX	0 - 127
Chord 2 volume	Chord2:	XXX	0 - 127
Chord 3 volume	Chord3:	XXX	0 - 127
Phrase 1 volume	Phrase1:	XXX	0 - 127
Phrase 2 volume	Phrase2:	XXX	0 - 127
Voice R1 volume	Upper1:	XXX	0 - 127
Voice R2 volume	Upper2:	XXX	0 - 127
Voice L volume	Lower:	XXX	0 - 127
Disk volume	Disk Vol:	XXX	0 - 127



TEMPO | MEAS | MEM | **096 | 001 | 01-1** 

R1

MixerSet

Rhythm\_m Vol: 108















Press [FUNCTION+/-] button to enter function menu. The default option of the menu is "Tune". When you enter the menu next time, you will find the option is the same as last time. Use [FUNCTION+/-] button to select the option to set. Use [+/YES]/[-/NO] or data dial to set parameter of the current option.

The option and parameters are as follows:

No.	Option	Range	Default
1	Tune	-50~+50	+00
2	Transpose	-12~+12	+00
3	Split Point	1~88	034
4	Beat Type	0, 2~9	004
5	Beat Volume	0~127	090
6	Harmony Switch	OFF, ON	OFF
7	Harmony Type	Duet, 1+5, Octave, CtryDuet, Trio,	Duet
<u>_</u>	Scale Switch	Block, 4Close1, 4Close2, 4Open OFF, ON	OFF
8		*	
9	Scale type	Pythagor, Major, Minor, MeanTone, Werckmei, Kirnberg	Pythagor
10	Scale Root	C, C#, D, D#, E, F, F#, G, G#,	С
		A, A#, B	
11	EQ type	Reset, Pop, Rock, Class, Jazz, Dance	Reset
12	DSP Effect	OFF, ON	ON
13	Reverb Type	Room1, Room2, Room3, Hall1, Hall2,	Hall1
		Church, Delay, PanDelay	
<u> </u>	Reverb Level	0~127	070
15	Chorus Type	Chorus1, Chorus2, GM Chrs1, GM	Chorus1
		Chrs2, Flanger1, Flanger2,Rotary1,	
		Rotary2	
16	Chorus Level	0~127	000
17	MIDI IN	1~16, ALL	ALL
18	MIDI OUT	1~16	001
19	Touch	OFF, 1, 2, 3	002
20	Language	中文,English	English
21	Power Off	OFF, 30, 60	030

#### **Tune**


This function sets the pitch of entire keyboard in 2-cent increments.


- 1. Press [FUNCTION+/-] button to select tune menu. LCD displays "Tune: xxx ". Use [+/YES]/[-/NO] or data dial to change tune value. Its range is from -50 to 50.
- 2. Press [+/YES] and [-/NO] simultaneously will set the tune value to its default setting:000.

#### **Transpose**


Transpose function allows the overall pitch of the instrument to be transposed up or down by a maximum of one octave in semitone steps.

- 1. Press [FUNCTION+/-] button to select transpose menu. LCD displays "Transpose: xxx". Use [+/YES]/[-/NO] or data dial to change transpose value. The range is±12 semitones.
- Press [+/YES]/[-/NO] simultaneously will set the transpose value to its default setting:000.





30 FunctionSet Tune: +00



	TEMPO <b>096</b>	MEAS <b>001</b>	MEM <b>01-1</b>
RI			

**®** FunctionSet Transpose:

+00

















#### **SplitPoint**

This function sets the point that separates the entire keyboard to two sections.

- Press [FUNCTION+/-] button to select SplitPoint menu. LCD displays "SplitPt: xxx". Use [+/YES]/[-/NO] or data dial to change SplitPoint value. The range of keyspilit: 1~88.
- 2. Press [+/YES] and [-/NO] simultaneously will set the SplitPoint value to its default setting: F#3(34).

#### Note:

When twinova is on, the range of keysplit is C3~C6(28~64). Press [+/YES] and [-/NO] simultaneously will set the SplitPoint value to its default setting: E3(32).

#### **Beat Type**

- 1. Press [FUNCTION+/-] button to select beat type menu. LCD displays "BeatType: xxx". Use [+/YES]/[-/NO] or data dial to change beat type. The range of beat type: 0, 2~9.
- 2. Press [+/YES] and [-/NO] simultaneously will set the beat type value to its default setting: 4.

#### **Beat Volume**

- Press [FUNCTION+/-] button to select beat volume menu. LCD displays "BeatVol: xxx". Use [+/YES]/[-/NO] or data dial to change beat volume. The range of beat volume: 0~127.
- 2. Press [+/YES] and [-/NO] simultaneously will set the beat volume value to its default setting: 090.

#### Harmony Switch

- 1. Press [FUNCTION+/-] button to select harmony switch menu. LCD displays "HarmonySw: xxx". Use [+/YES]/[-/NO] or data dial to change harmony switch status: OFF,ON.
- 2. Press [+/YES] and [-/NO] simultaneously will set harmony switch to default setting: OFF.

#### Playing with harmony:


Turn on the A.B.C function, then play a chord in the left hand area. When you play in the right hand area, it will automatically add a harmony effect to the notes.

Harmony types "1+5" and "octave" are always available, while the rest are effective only when A.B.C is on.

#### **Harmony Type**

You can add a variety of harmony notes to the keys you played in the right-hand section.

 Press [FUNCTION+/-] button to select harmony type menu. LCD displays "HarmonyTp: xxx". Use [+/YES]/[-/NO] or data dial to change harmony type.




TEMPO MEAS MEM **096 001 01-1** 

R1

FunctionSet SplitPt:

**034** 




TEMPO MEAS MEM **096 001 01-1** 

R1

FunctionSet BeatType:

004




TEMPO MEAS MEM **096 001 01-1** 

RI)

FunctionSet BeatVol:

090



TEMPO MEAS MEM **096 001 01-1** 

യ FunctionSet

HarmonuSu:

OFF

TEMPO MEAS MEM **096 001 01-1** 

R1

FunctionSet HarmonyTp:

'p: Duet















There are 9 harmony types in this instrument.

Parameter	LCD Display
Duet	Duet
1+5	1+5
Octave	Octave
Country Duet	CtryDuet
Trio	Trio
Block	Block
4 Close 1	4Close1
4 Close 2	4Close2
4 Open	4Open

2. Press [+/YES] and [-/NO] simultaneously will set harmony type to default setting: Duet.

#### Scale Switch

The equal temperament (has only one tuning method, and is suitable for keyboard instrument) is commonly used in modern music, based on this temperament method to make your own composition and performance. Especially for piano, equal temperament is widely used and taken for granted. But people used several other scales to compose and perform before adopting the equal temperament.

- 1. Press [FUNCTION+/-] button to select scale switch menu. LCD displays "ScaleSw: xxx". Use [+/YES]/[-/NO] or data dial to change Scale switch status: OFF, ON.
- 2. Press [+/YES] and [-/NO] simultaneously will set scale switch to default setting: OFF.

Scale Type

1. Press [FUNCTION+/-] button to select scale type menu. LCD displays "ScaleType: xxx". Use [+/YES]/[-/NO] or data dial to change scale type.


There are 6 scale types in this instrument.


Parameter	LCD Display
Pythagorean	Pythagor
Pure Major	Major
Pure Minor	Minor
Meantone	MeanTone
Werkmeister	Werckmei
Kirnberger	Kirnberg


2. Press [+/YES] and [-/NO] simultaneously will set scale type to default setting: Pythagor.

#### Scale Root

- 1. Press [FUNCTION+/-] button to select scale root menu. LCD displays "ScaleRoot: xxx". Use [+/YES]/[-/NO] or data dial to change scale root: C, C#, D, D#, E, F, F#, G, G#, A, A#, B.
- 2. Press [+/YES] and [-/NO] simultaneously will set scale root to default setting: C.







	096	001	01-1
R1			
Function	nSet		
ScaleRo	ot		С















へ / YES

**EQ Type** 

EQ function can control the gain of different frequency band. And different gain settings produce different sound field effects.

1. Press [FUNCTION+/-] button to select EQ type menu. LCD displays "EqType: xxx". Use [+/YES]/[-/NO] or data dial to change EQ type.

There are 6 EQ types in this instrument.

Parameter	LCD Display
Reset	Reset
Pop	Pop
Rock	Rock
Class	Class
Jazz	Jazz
Dance	Dance

2. Press [+/YES] and [-/NO] simultaneously will set EQ type to default setting: Reset.

#### **DSP Effect**

- 1. Press [FUNCTION+/-] button to select DSP effect menu. LCD displays "DspEffect: xxx". Use [+/YES]/[-/NO] or data dial to change DSP switch status: OFF, ON.
- 2. Press [+/YES] and [-/NO] simultaneously will set DSP switch to default setting: ON.

**Reverb Type** 

1. Press [FUNCTION+/-] button to select reverb type menu. LCD displays "ReverbType: xxx". Use [+/YES]/[-/NO] or data dial to change reverb type.

There are 8 reverb types in this instrument.

Parameter	LCD Display
Room 1	Room1
Room 2	Room2
Room 3	Room3
Hall 1	Hall1
Hall 2	Hall2
Church	Church
Delay	Delay
Pan Delay	PanDelay


2. Press [+/YES] and [-/NO] simultaneously will set reverb type to default setting: Hall1.


#### Reverb Level

1. Press [FUNCTION+/-] button to select reverb level menu. LCD displays "ReverbLev: xxx". Use [+/YES]/[-/NO] or data dial to change reverb level.


The range of reverb level: 0~127.


2. Press [+/YES] and [-/NO] simultaneously will set reverb level to default: 070.





FUNCTION

















**Chorus Type** 

1. Press [FUNCTION+/-] button to select chorus type menu. LCD displays "ChorusType: xxx". Use [+/YES]/[-/NO] or data dial to change chorus type.

There are 8 chorus types in this instrument.

Parameter	LCD Display
Chorus 1	Chorus1
Chorus 2	Chorus2
GM Chorus 1	GM Chrs1
GM Chorus 2	GM Chrs2
Flanger 1	Flanger1
Flanger 2	Flanger2
Rotary 1	Rotary1
Rotary 2	Rotary2

2. Press [+/YES] and [-/NO] simultaneously will set chorus type to default setting: Chorus1.

#### Chorus Level

1. Press [FUNCTION+/-] button to select chorus level menu. LCD displays "ChorusLev: xxx". Use [+/YES]/[-/NO] or data dial to change chorus level.

The range of chorus level: 0~127.

2. Press [+/YES] and [-/NO] simultaneously will set chorus level to default: 000.

#### MIDI IN

- 1. Press [FUNCTION+/-] button to select MIDI IN menu. LCD displays "Midiln: xxx". Use [+/YES]/[-/NO] or data dial to change MIDI IN channel:1~16,ALL.
- 2. Press [+/YES] and [-/NO] simultaneously will set MIDI IN channel to default setting: ALL.


#### MIDI OUT

- 1. Press [FUNCTION+/-] button to select MIDI OUT menu. LCD displays "MidiOut: xxx". Use [+/YES]/[-/NO] or data dial to change MIDI OUT channel:1~16.
- 2. Press [+/YES] and [-/NO] simultaneously will set MIDI OUT channel to default setting: 001.

#### Touch

The keyboard is equipped with a touch response feature that lets you dynamically and expressively controls the level of the voice with your playing strength just as on an acoustic instrument.


- 1. Press [FUNCTION+/-] button to select touch menu. LCD displays "Touch: xxx". Use [+/YES]/[-/NO] or data dial to change touch type: OFF, 1(soft), 2(normal), 3(hard).
- 2. Press [+/YES] and [-/NO] simultaneously will set touch value to default setting: 2(normal).



 $\overline{\mathbb{R}1}$ 

FunctionSet

ChorusType: Chorus1




TEMPO | MEAS | MEM 096 001 01-1

RI

FunctionSet ChorusLev:


000



TEMPO MEAS MEM 096 | 001 | 01-1 R1FunctionSet

MidiIn: ALL

TEMPO MEAS MEM 096 | 001 | 01-1 R1FunctionSet MidiOut: 001



TEMPO|MEAS| MEM 096 | 001 | 01-1

R1

FunctionSet

Touch: 002

22













#### Language


This function is used to set the system language.

- 1. Press [FUNCTION+/-] button to select language menu. LCD displays "Language: xxx". Use [+/YES]/[-/NO] or data dial to change language: 中文, English
- 2. The language setting will not be lost after power off.

#### **PowerOff**

This function is used to set the time of automatic shutdown.

- Press [FUNCTION+/-] button to select power off menu. LCD displays "PowerOff: xxx". Use [+/YES]/[-/NO] or data dial to change time value: OFF, 030, 060
- Press [+/YES] and [-/NO] simultaneously, the time will be restore default: 030 minutes



The keyboard is an instrument with a variety of controls and functions, the Registration Memory feature can make your performance more easily and efficiently. It allows you to save virtually all panel settings to a Registration Memory setting, and you can instantly recall custom panel settings by pressing a single button.

#### Registering the Panel Setting

- 1. There are 24 memory banks, each bank has 4 memories (M1-M4).
- 2. Hold down the [STORE] button, then press one of the REGISTRA-TION MEMORY buttons: [M1] - [M4]. Notice that the new settings will replace the previous memory data.

### **Recalling the Registered Panel Settings**

Press one of the MEMORY buttons [M1] - [M4] to recall a panel setting.

For example, press [M3] and LCD shows "01-3". It will recall a setting from memory 3 of bank 1.


#### Note:

Registration data cannot be recalled when the One Touch Setting function is on.

### Selecting a Registration Bank

- 1. Press the [BANK] button. There are 24 banks at all and each bank has 4 memories(M1-M4). Press the [BANK] button, the LCD displays "MemBank".
- 2. Select a bank. Use the data Ddal, [+/YES] or [-/NO] button to select a bank from 1 to 24.

### **Register Memory**















### Song Recording

With the easy-to-use song recording features, you can record your own keyboard performances as a user song. 10 user songs can be recorded with 6 tracks (1 ACCOMP track, 5 MELODY tracks) each. The accomp track records the accompaniment for a user song, while the melody tracks record melodies for a user song.

An accomp track and a melody track can be recorded independently or together, however, you can not record two melody tracks at the same time.

You can play back the accomp track and melody tracks together. The saved data will not be lost after power off.

#### Start Recording

Before recording starts, you will need to select a user song to which your recording will be saved.

- 1. Holding down [SHIFT] button, then press [RECORD] button to enter the user song selection interface. The LCD displays "RecSong1" and sequence number. 10 user songs can be recorded. Press [+/YES] / [-/NO] button to select the user song you want.
- 2. Hold down [SHIFT] button, then press [RECORD] button again to enter the recording standby mode. "REC" appears on LCD, and the [START/STOP] LED on the panel lights up. It will automatically select an empty track to record your performance. LED of the selected track (ACCOMP, MELODY1 -MELODY 5) will flash on the panel.
- 3. In recording standby mode, you can select your desired voice, style

Hold down [SHIFT] button, then Press [Accomp] or [Melody1] -[Melody 5] to select a different track. LED of the selected track will light up on the panel.

An accomp track and a MELODY track can be recorded together. but it cannot record two melody tracks simultaneously.

4. Press [START/STOP] button or play the keyboard to start recording. The [RECORD] LED will light up.

When the accomp track is selected and A.B.C is on, recording will start as soon as you play a chord in the left hand area.

#### Note:

Style can only be recorded in "Accomp" track.


Track indicators on the left of LCD usually shows one of three states: blinking, light up, light off. Press the track buttons repeatedly to shift between different states.

Blinking: the track is selected for recording. All existing data will be over-written.

Light up: the track has data and will play back the data during recording.

Light off: the track either has no data or is under recording and cannot play back.

In recording standby mode, the keyboard will automatically select the empty track next to the occupied track. For example, if "Melody 1" is occupied, "Melody 2" will be selected as the record track. When all 6 tracks have been recorded and a specific track needs to be revised, press the button of that track and start recording. The original data will be replaced.

















### Song Recording

#### Stop Recording


- 1. When recording is in process, holding down [SHIFT] button then press the [RECORD] button to stop recording.
- 2. When recording is in process, if the memory is full, the recording will stop and save automatically, the LCD displays "RecFull".
- 3. If you are recording a style, the recording will stop automatically when the ending of the rhythm finishes.


#### **Playback Recording**


- 1. When recording is in process, holding down [STORE] button then press the [RECORD] button, it will stop recording and enter the song mode, and the current recorded song will play automatically in circle.
- 2. Press the [SONG] button to enter the song mode and it will play all songs circularly. Use the data dial, [+/YES] or [-/NO] button to select a song number from 121-130 (corresponding to the 10 user songs). If there is no data in the selected user song, it will display "Nofile" and stop playing.
  - Alternatively, when the playback stops, you can select a user song and then press [PLAY/STOP] button to play the song in a loop.

#### **Delete User Song**

- 1. Pressing and holding [RECORD] and [STORE] button together and turn power on simultaneously, all user songs will be erased.
- 2. In the recording standby mode, holding down [SHIFT] button then press the [RECORD] button for two second, the LCD will display "Delete?". And holding down [SHIFT] button then press the [Accomp] (or [Melody1] to [Melody 5]) button to select the track you want to delete. The track selected will light up. If all tracks light up, it will delete the user song after confirmation.
- 3. Press [+/YES] to confirm and the recorded data in this track will be erased. Press [-/NO] to quit this step, and go back to recording standby mode.





















### Song

The piano has 130 songs in all, including 10 user songs.

#### Listening to the songs

- 1. Press the [SONG] button to enter the song mode and it will play all songs circularly.
- 2. Use the data dial, [+/YES] or [-/NO] button to select a song.
- 3. In song mode, press the [START/STOP] button, it will play current song repeatedly.
- 4. When playback stops, press [STYLE] or [VOICE] button to exit song mode.

#### Song Control

1. Introductory beat

Before song starts playing, it has the introductory beat, the measure starts from negative value. It begins to play song when the measure goes to 1.

2. REW, FF and PAUSE

When the song is playing:

Press the [FF] button to fast forward the song.

Press the [REW] button to rewind the song (base on the measure). Press the [PAUSE] button to pause the playing song.

3. Song Repeat


During song playback, press [REPEAT A/B] button to set the beginning for a loop section of the current song, then press it again to set the loop end. During loop playback, press [REPEAT A/B] button to quit the loop and go back to song playback.


#### Practice the song

In song mode, press [MELODY OFF L/R] button to turn on/off the left or right hand part, so as to practise each part separately.

A lit "L" on LCD indicates only the left hand melody will play and the right hand part will be muted, so you can practise the right hand

In the same way, a lit "R" on LCD means you can practise the left hand part along with the right hand melody.





### **Restore Factory Setting**

Pressing and holding [+/YES] and [-/NO] button together and then turn the power on, the piano would be restored to factory setting. It will delete all the user data: user styles, user songs, registered memory. The process will last about 8 seconds, after which the piano will start up normally.























## **Connecting USB Flash Drive**

The piano recognizes USB flash drives, sizing from 16M to 32G in the format of FAT16 or FAT32.

We recommend to format the USB flash drive on the piano before using. Do not edit the backup files saved in the USB flash drive.


#### **USB Flash Drive Operation**


- 1. The function buttons related to USB Flash Drive are: [USB DEVICE], [+/YES], [-/NO], [START/STOP] and the data dial.
- 2. Press [USB DEVICE] button to enter USB mode, and press it again can guit that mode.
- 3. If the USB Flash Drive has been inserted before pressing [USB DEVICE] button, the LCD displays a waiting notice, the upper right corner of LCD displays icon 🖺 . If initialization succeeds, LCD displays "Play", the icon becomes 🚮 . If initialization failed, the LCD displays "DiskErr", and the icon remains []. If USB Flash Drive is not inserted, the LCD displays "NoDisk", the upper right corner of LCD does not display USB Flash Drive icon.
- 4. In USB mode, use data dial to select menu, press [+/YES] button to proceed, press [-/NO] to go back.
- 5. In USB mode, it can read a maximum of 512 files in one folder. Icon represents folder, icon represents file.
- 6. In USB mode, press [USB DEVICE], voice direct button, style direct button can exit USB device mode.
- 7. Press [MIXER] button can change the volume when playing MIDI file.
- 8. In USB mode, the operation to load, save or delete will apply to files in the "MMKD" folder only.

The "MMKD" folder will be generated automatically when user data is saved to the USB flash drive.


#### **Play**

- 1. Press [USB DEVICE] button to enter USB mode. Then use data dial to select "Play" menu.
- 2. Press [+/YES] button, LCD will display the name of MIDI files and sub directories in the root of the USB Flash Drive.
- 3. If you choose a sub-directory, press [+/YES] button to open the folder, press [-/NO] to return to the root directory. If LCD displays "..", pressing [+/YES] button will return to the previous directory.
- 4. Use data dial to select a midi MIDI file, press [START/STOP] button to play it repeatedly. Press [+/YES] button to play all files in the current directory circularly. Press [START/STOP]button again to stop playing,























### **Connecting USB Flash Drive**

#### Save

- 1. Press [USB DEVICE] button to enter USB mode. Then use data dial to select "Save".
- Press [+/YES] to enter "Save" sub menu. It includes "SaveSong", "SaveSty", "SaveMem". Use [+/YES], [-/NO]button or data dial to select one.

#### Save user song:

- Select the menu "SaveSong" sub menu and press [+/YES] button, LCD displays the user song name and number. Use the data dial to select the file to save.
- After selected the user song, press [+/YES]. The LCD prompts to enter file name "SNG\_". Now use keyboard to enter 8 character file name.
- 3. After entering the file name, press [+/YES]. The LCD prompts to confirm the operation: "Sure?". Press [+/YES] again to save the file. Press [-/NO] to cancel the operation.
- 4. If the name you enter is the same with the song name in USB Flash Drive, the LCD prompts "SameName!". You need to enter a different name to save file.
  - Follow the steps above to save a user style or a user memory.

#### Load

- Press [USB DEVICE] button to enter USB mode. Then use data dial to select "Load" menu.
- Press [+/YES] to enter "load" submenu. Load submenu are displayed on LCD, it includes "LoadSong", "LoadSty", "LoadMem". Use [+/YES], [-/NO]button or data dial to select one.

#### Load Song:

- Select the menu "LoadSong" and press [+/YES] button, LCD displays the MIDI files(\*.midi) in the MMKD\SONG directory of USB Flash Drive. Use the data dial to select the file to load.
- 2. After selected the midi file, press [+/YES]button , and then use the data dial to select user song number.
- 3. After selected the song number, press [+/YES] button, and the LCD displays "Sure?". Press [+/YES] again to confirm the loading operation. Press [-/NO] to cancel the that operation.

#### Load Style

- Select the menu "LoadSty" and press [+/YES] button, LCD displays the style files(\*.sty) in the MMKD\STYLE directory of USB Flash Drive. Use the data dial to select the file to load.
- After selected the style file, press [+/YES] button, and then use the data dial to select user style number.
- 3. After selected the user style number, press [+/YES] button, and the LCD displays "Sure?". Press [+/YES] again to confirm the loading operation. Press [-/NO] to cancel the that operation.





	TEMPO <b>120</b>	MEAS <b>001</b>	MEM <b>01-1</b> 5/
<b>3)</b> DiskMen	u		
Save			

TEMPO MEAS MEM
120 001 01-15/

Save
SaveSong

	TEMPO <b>120</b>	MEAS <b>001</b>	MEM <b>01-1</b> 6	3/
<b>31</b>				
SaveSon PSNG_	ng			





TEMPO MEAS MEM 120 001 01-10/ DiskMenu Load

| TEMPO | MEAS | MEM | 120 | 001 | 01-10/ | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120

TEMPO MEAS MEM 120 001 01-10/ 20 LoadSong FSNG001 001

TEMPO MEAS MEM 120 001 01-10/ 30 Load LoadSty

28















#### **Load Memory**

- 1. Select the menu "LoadMem" and press [+/YES] button, LCD displays the memory files(\*.mem) in the MMKD\MEMORY directory of USB Flash Drive. Use the data dial to select the file to load.
- 2. After selected the memory file, press [+/YES] button, and then use the data dial to select user memory number.
- 3. After selected the user memory number, press [+/YES] button, and the LCD displays "Sure?". Press [+/YES] again to confirm the loading operation. Press [-/NO] to cancel the that operation.

#### **Delete**

- 1. Press [USB DEVICE] button to enter USB mode. Then use data dial to select "Delete".
- 2. Press [+/YES] to enter "Delete" sub menu. It includes "UserSong", "UserSty", "UserMem". Use [+/YES], [-/NO] button or data dial to
- 3. After selected file type to delete, press [+/YES] to enter the corresponding menu.
- 4. After selected the file to delete, press [+/YES], and the LCD displays "Sure?". Press [+/YES] to confirm, and press [-/NO] to cancel the operation.

#### **Format**

- 1. Press [USB DEVICE] button to enter USB mode. Then use data dial to select "Format".
- 2. Press [+/YES] to confirm. LCD displays "Sure?", then press [+/YES] to format, press [-/NO] to cancel operation.


#### Note:


Formation will delete all data in USB Flash Drive!

#### **Keyboard and ASCII Character Relative Table**


itcyboo	ai u ui	iu Au	011 0	i iui uc	toi it	Ciativ	c iub	10			
NOTE	C#2	D2	Eb2	E2	F2	F#2	G2	Ab2	A2	Bb2	B2
LETTER	DEL	BACK	NEXT	Α	В	С	D	Е	F	G	Н
NOTE	C3	C#3	D3	Eb3	E3	F3	F#3	G3	Ab3	A3	Bb3
LETTER	I	J	K	L	M	N	0	Р	Q	R	S
NOTE	В3	C4	C#4	D4	Eb4	E4	F4	F#4	G4	Ab4	A4
LETTER	Т	U	V	W	Х	Υ	Z	0	1	2	3
NOTE	Bb4	B4	C5	C#5	D5	Eb5					
LETTER	4	5	6	7	8	9					

### **Connecting USB Flash Drive**





	TEMPO	MEAS	MEM
	<b>120</b>	<b>001</b>	<b>01-15</b> /
🔊 Delete UserSty	I		

















By using the MIDI functions you can expand your musical possibilities. This section explains what MIDI is, and what it can do, as well as how you can use MIDI on your instrument.

#### What's MIDI?

MIDI (short for Musical Instrument Digital Interface) allows a wide variety of electronic musical instruments, computers and other related devices to connect and communicate with one another. MIDI carries event messages that specify notation, pitch and velocity, control signals for parameters such as volume, vibrato, audio panning, and program change information to change the voice selections.

The instrument can output the real-time playback information via MIDI messages and control external MIDI devices. The instrument can also accept incoming MIDI messages and generate sound accordingly.

#### **Downloading Data from the Computer**


Connect a standard USB cable between the rear-panel of the USB jack of the instrument and the USB jack on your computer. Power on the instrument first, and then open the PCSUITE software in your computer, the "CONNECTING" will be displayed on LCD. The PCSUITE will connect successfully with the instrument.


You can download 5 SMF MIDI files to the keyboard as user songs or upload the user songs.

You can upload user styles to the computer as a backup or download them to the keyboard.

You can upload memory files to the computer as a backup or download them to the keyboard.

Please refer to software operation instructions for detail operating methods.



















Problem	Possible Cause and Solution
The speakers produce a pop sound whenever the power is turned ON or OFF.	This is normal and is no cause for alarm.
No sound when the keyboard is played.	Make sure the master volume is set to an appropriate level. Check if headphones are plugged into Jack 1. The R1/R2/L voice volume (Mixer) settings could be set too low. Make sure the voice volumes are set at appropriate levels.
When using a mobile phone, noise is produced.	Using a mobile phone in close proximity to the instrument may produce interference. To prevent this, turn off the mobile phone or use it further away from the instrument.
The auto accompaniment does not play back even Sync is in standby condition and a key is pressed.	You may be trying to start accompaniment by playing a key in the right-hand range of the keyboard. To start the accompaniment with Sync Start, make sure to play a key in the left-hand range of the keyboard.
Certain notes sound at wrong pitch.	Make sure that the tuning value is set to 0. Press and hold the [+/YES] and [-/NO] buttons at the same time, then turning the power on will set INSTRUMENT to default.
The Harmony function does not operate.	Please make sure the Harmony function is on. And Harmony cannot be turned on when a drum kit is selected for the voice R1.
After connecting with the computer, the piano is not recognized.	Please check if the USB cable is being connected firmly,or try connecting another USB port of the computer,without the need to install another driver on the PC.

### **Specifications**

#### **LCD Display**

Multi-functional LCD

#### Keyboard

88 Hammer-Action Keys

#### **Polyphony**

128

#### Voice

600

#### Song

120 preset songs, 10 user songs

230 preset styles, 10 user styles

#### Demo

#### **Control button**

Power Switch, Volume knob, Brilliance knob, Styles, Tempo+/-, Acc Vol, Mixer, Function+/-, Start/Stop, Sync Start, Intro/ Ending, Fill A, Fill B, Fill C Fill D, Chord Mode, Voices, Dual, Lower, USB Device, Metro, Twinova, Octave, Song, Bank, Store, M1-M4, O.T.S., Shift, Demo, +/Yes, -/No, Data dial, Melody off L/R

#### **Record Function**

Record, Accomp, Melody 1-5

#### Memory

96

#### Connectors

PHONES (2 standard. 1/4" phone), AUX IN, AUX OUT USB-MIDI, USB Device Jack Pedals (Sustain, Soft, Sostenuto), SPEAKER Jack

#### **Power Supply**

DC IN 15V

#### Speaker

4 ohm 15W X 2

#### **Dimensions**

1421(L) X 306(W) X 788(H) mm

#### Weight

38KG

\* All specifications and appearances are subject to change without notice.













No.	Full Name
Piano	
1	Acoustic Grand Piano
2	Acoustic Grand Piano 2
3	Acoustic Grand Piano 3
4	Acoustic Grand Piano (wide)
5	Acoustic Grand Piano (dark)
6	Bright Acoustic Piano
7	Bright Acoustic Piano 2
8	Bright Acoustic Piano 3
9	Bright Acoustic Piano (wide)
10	Electric Grand Piano
11	Electric Grand Piano 2
12	Electric Grand Piano (wide)
13	Electric Grand Piano (dark)
14	Honky Tonk Piano
15	Honky Tonk Piano 2
16	Honky Tonk Piano (wide)
17	Honky Tonk Piano (dark)
18	Harpsichord
19	Harpsichord 2
20	Harpsichord (octave mix)
21	Harpsichord (wide)
22	Harpsichord (with key off)
23	Octave Grand Piano
24	Octave Grand Piano 2
25	Piano & Strings
26	Piano & Pad
27	Piano & Choir
28	Piano & EP
29	Piano & Vibraphone
30	Detuned Electric Piano
31	Detuned Electric Piano 2
32	Electric Piano
33	Electric Piano 2
34	Electric Piano 3
35	Electric Piano 4
36	Electric Piano 1 (velocity mix)
37	Electric Piano 2 (velocity mix)
38	60's Electric Piano
39	EP Legend
40	Phase EP
41	Clavi
42	Clavi 2
43	Phase Clavi
44	Wah Clavi
45	Pulse Clavi
46	Dream EP
47	Tremolo EP
48	Funk EP
49	Warm EP
50	Choir EP
51	Wah EP
52	Modern EP
53	EP Pad
	natic Percussion
54	Celesta
55	Celesta 2

56	Celesta 3
57	Glockenspie
58	Glockenspiel 2
59	Music Box
60	Music Box 2
61	Music Box 3
62	Vibraphone
63	Vibraphone 2
64	Vibraphone (wide)
65	Marimba
66	Marimba 2
67	Marimba 2  Marimba (wide)
	, ,
68	Xylophone
69	Xylophone 2
70	Xylophone 3
71	Tubular Bells
72	Tubular Bells 2
73	Church Bell
74	Carillon
75	Dulcimer
76	Dulcimer 2
77	Santur
Organ	
78	Italian 60's Organ
79	Drawbar Organ
80	Drawbar Organ 2
81	Detuned Drawbar Organ
82	Drawbar Organ 3
83	Detuned Percussive Organ
84	Percussive Organ
85	Percussive Organ 2
86	70's Percussive Organ
87	Percussive Organ 3
88	Rock Organ
	Rock Organ 2
89	
90	Rock Organ 3
91	Church Organ
92	Church Organ 2
93	Church Organ 3
94	Church Organ (octave mix)
95	Detuned Church Organ
96	Reed Organ
97	Reed Organ 2
98	Rotary Organ
99	Puff Organ
100	Accordion
101	Accordion 2
102	Accordion 3
103	Harmonica
104	Harmonica 2
105	Harmonica 3
106	Tango Accordion
107	Tango Accordion 2
Guitar	
108	Acoustic Guitar (nylon)
109	Acoustic Guitar (nylon) 2
110	Acoustic Guitar (nylon) 3
	Acoustic Guitar (nylon) 5 Acoustic Guitar (nylon + key off)
111	Acoustic Guitai (Hylon + key Oll)











112	Ukulele
113	Acoustic Guitar (steel)
114	Acoustic Guitar (steel) 2
115	12-Strings Guitar
116	Mandolin
117	Mandolin 2
118	Steel Guitar with Body Sound
119	Electric Guitar (jazz)
120	Electric Guitar (jazz) 2
121	Electric Guitar (pedal steel)
122	Electric Guitar (clean)
123	Electric Guitar (clean) 2
124	Electric Guitar (detuned clean)
125	Mid Tone Guitar
126	Electric Guitar (muted)
127	Electric Guitar (muted) 2
128	Electric Guitar (funky cutting)
129	Electric Guitar (muted velo-sw)
130	Jazz Man
131	Overdriven Guitar
132	Overdriven Guitar 2
132	Guitar Pinch
133	Distortion Guitar
134	
	Distortion Guitar 2
136	Distortion Guitar (with feedback)
137	Guitar Feedback
138	Distorted Rhythm Guitar
139	Guitar Harmonics
140	Guitar Harmonics 2
141	Velocity Nylon Guitar
Bass	
	A (; D
142	Acoustic Bass
143	Acoustic Bass 2
143 144	Acoustic Bass 2 Wah Bass
143 144 145	Acoustic Bass 2 Wah Bass Electric Bass (finger)
143 144 145 146	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass
143 144 145 146 147	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick)
143 144 145 146 147 148	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2
143 144 145 146 147 148 149	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass
143 144 145 146 147 148 149	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2
143 144 145 146 147 148 149 150	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass
143 144 145 146 147 148 149 150 151	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass Slap Bass 2
143 144 145 146 147 148 149 150 151 152	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass Slap Bass 3
143 144 145 146 147 148 149 150 151 152 153	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass 2 Slap Bass 3 Slap Bass 4
143 144 145 146 147 148 149 150 151 152 153 154 155	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass 2 Slap Bass 3 Slap Bass 4 Synth Bass
143 144 145 146 147 148 149 150 151 152 153 154 155	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass 2 Slap Bass 3 Slap Bass 4 Synth Bass 2
143 144 145 146 147 148 149 150 151 152 153 154 155 156	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass 2 Slap Bass 3 Slap Bass 4 Synth Bass 2 Synth Bass 2 Synth Bass 3
143 144 145 146 147 148 149 150 151 152 153 154 155 156 157	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass 2 Slap Bass 3 Slap Bass 4 Synth Bass 2 Synth Bass 2 Synth Bass 3 Synth Bass 3 Synth Bass 3
143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass 3 Slap Bass 3 Slap Bass 4 Synth Bass 2 Synth Bass 3 Synth Bass 4 Warm Synth Bass
143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass 2 Slap Bass 3 Slap Bass 4 Synth Bass 2 Synth Bass 2 Synth Bass 3 Synth Bass 4 Warm Synth Bass Rsonance SynBass
143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159 160	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass 2 Slap Bass 3 Slap Bass 4 Synth Bass Synth Bass 2 Synth Bass 3 Synth Bass 4 Warm Synth Bass Rsonance SynBass Clavi Bass
143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159 160 161	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass 2 Slap Bass 2 Slap Bass 3 Slap Bass 4 Synth Bass Synth Bass 2 Synth Bass 3 Synth Bass 4 Warm Synth Bass Rsonance SynBass Clavi Bass Hammer
143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159 160	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass 2 Slap Bass 3 Slap Bass 4 Synth Bass Synth Bass 2 Synth Bass 3 Synth Bass 4 Warm Synth Bass Rsonance SynBass Clavi Bass
143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159 160 161	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass 2 Slap Bass 2 Slap Bass 3 Slap Bass 4 Synth Bass Synth Bass 2 Synth Bass 3 Synth Bass 4 Warm Synth Bass Rsonance SynBass Clavi Bass Hammer
143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 160 161 162	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass 2 Slap Bass 3 Slap Bass 3 Slap Bass 4 Synth Bass 2 Synth Bass 2 Synth Bass 3 Synth Bass 4 Warm Synth Bass Rsonance SynBass Clavi Bass Hammer Attack Bass Synth Bass (rubber) Synth Bass (rubber) 2
143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 160 161 162 163 164 165	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass 2 Slap Bass 3 Slap Bass 3 Slap Bass 4 Synth Bass 2 Synth Bass 2 Synth Bass 3 Synth Bass 3 Synth Bass 4 Warm Synth Bass Rsonance SynBass Clavi Bass Hammer Attack Bass Synth Bass (rubber) Synth Bass (rubber) 2 Attack Pulse
143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 160 161 162 163 164 165	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass 2 Slap Bass 3 Slap Bass 3 Slap Bass 4 Synth Bass 2 Synth Bass 2 Synth Bass 3 Synth Bass 4 Warm Synth Bass Rsonance SynBass Clavi Bass Hammer Attack Bass Synth Bass (rubber) Synth Bass (rubber) Synth Bass (rubber) Attack Pulse  8 Orchestral
143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 160 161 162 163 164 165 166	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass 2 Slap Bass 3 Slap Bass 3 Slap Bass 4 Synth Bass 2 Synth Bass 2 Synth Bass 3 Synth Bass 3 Synth Bass 4 Warm Synth Bass Rsonance SynBass Clavi Bass Hammer Attack Bass Synth Bass (rubber) Synth Bass (rubber) 2 Attack Pulse
143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159 160 161 162 163 164 165 166 String	Acoustic Bass 2 Wah Bass Electric Bass (finger) Finger Slap Bass Electric Bass (pick) Electric Bass (pick) 2 Fretless Bass Fretless Bass 2 Slap Bass 2 Slap Bass 3 Slap Bass 4 Synth Bass 2 Synth Bass 2 Synth Bass 3 Synth Bass 4 Warm Synth Bass Rsonance SynBass Clavi Bass Hammer Attack Bass Synth Bass (rubber) Synth Bass (rubber) Synth Bass (rubber) Attack Pulse  8 Orchestral

160	Violin (clay attack)
169	Violin (slow attack)
170	Viola
171	Viola 2
172	Cello
173	Cello 2
174	Contrabass
175	Contrabass 2
176	Tremolo Strings
177	Tremolo Strings 2
178	Tremolo Strings 3
179	Pizzicato Strings
180	Pizzicato Strings 2
181	Orchestral Harp
182	Orchestral Harp 2
183	Yang Chin
184	Timpani
185	Timpani 2
186	String Ensembles
187	String Ensembles 2
188	String Ensembles 3
189	String Ensembles 4
190	Strings & Brass
191	60's Strings
192	Synth Strings
193	Synth Strings 2
194	Synth Strings 3
195	Synth Strings 4
196	Synth Strings 5
197	Choir Aahs
198	Choir Aahs 2
199	Choir Aahs 3
200	Voice Oohs
201	Voice Oohs 2
202	Humming
203	Anlong Voice
204	Synth Voice
205	Synth Voice 2
206	Orchestra Hit
207	Orchestra Hit 2
208	Bass Hit Plus
209	6th Hit
210	Euro Hit
Brass	
211	Trumpet
212	Trumpet 2
213	Dark Trumpet
214	Trombone
215	Trombone 2
216	Trombone 3
217	Bright Trombone
218	Tuba
219	Tuba 2
220	Muted Trumpet
221	Muted Trumpet  Muted Trumpet 2
222	Muted Trumpet 2  Muted Trumpet 3
223	French Horn
224	French Horn 2
225	French Horn 3
220	T TOTION THOMAS









226	Brass Section
227	Brass Section 2
228	Brass Section 3
229	Synth Brass
230	Synth Brass 2
231	Synth Brass 3
232	Synth Brass 4
233	Synth Brass 5
234	Synth Brass 6
235	Synth Brass 7
236	Synth Brass 8
237	Analog Synth Brass
238	Analog Synth Brass 2
239	Analog Synth Brass 3
240	Jump Brass
241	Jump Brass 2
242	Funny
243	Funny 2
Reed	
244	Soprano Sax
245	Soprano Sax 2
246	Soprano Sax 3
247	Alto Sax
248	Alto Sax 2
249	Alto Sax 3
250	Tenor Sax
251	Tenor Sax 2
252	Tenor Sax 3
253	Baritone Sax
254	Baritone Sax 2
255	Baritone Sax 3
256	Oboe
257	Oboe 2
258	Oboe 3
259	2 Oboes
260	English Horn
	9
261	English Horn 2 English Horn 3
262	•
263	2 English Horns
264	Bassoon
265	Bassoon 2
266	Bassoon 3
267	2 Bassoons
268	Clarinet
269	Clarinet 2
270	Clarinet 3
271	2 Clarinets
Pipe	
272	Piccolo
273	Piccolo 2
274	Piccolo 3
275	2 Piccolos
276	Sweet Flute
277	Flute
278	Flute 2
279	Flute 3
280	2 Flutes
281	Recorder
201	1.000.00.

282	Recorder 2
283	2 Recorders
284	Pan Flute
285	Pan Flute 2
286	Sweet Pan Flute
287	Blown Bottle
288	Blown Bottle 2
289	Shakuhachi
290	Shakuhachi 2
291	Whistle
292	Whistle 2
293	Ocarina
294	Ocarina 2
Synth	l ead
295	Lead 1 (square)
296	Lead 1a (square) 2
297	Lead 1 (square) 3
298	Lead 1b (sine)
299	Lead 2 (sawtooth)
300	Lead 2a (sawtooth) 2
300	Lead 2 (sawtooth) 3
302	Lead 2b (saw + pulse)
303	Lead 2c (double sawtooth)
304	Lead 2d (sequenced analog)
305	Lead 2d (sequenced analog)  Lead 2d (sequenced analog) 2
306	Wavy Sawtooth
307	Bauble Lead
308	Super Analog
	Lead 3 (calliope)
309	` ' '
310	Lead 3 (calliope) 2
311	Lead 4 (chiff) Lead 4 (chiff) 2
312	Lead 4 (chiff) 3
314	Lead 5 (charang)
315	Lead 5 (charang) 2
316	Lead 5 (charang) 3
317	Lead 5 (charang) 4
318	Lead 5a (wire lead)
319	Lead 5a (wire lead) Lead 5a (wire lead) 2
	Lead 6 (voice)
320	Lead 6 (voice) 2
321	Lead 7 (fifths)
323	Lead 7 (fifths) 2
323	Lead 8 (bass + lead)
324	Lead 8 (bass + lead) 2
326	Lead 8 (bass + lead) 3
327	Lead 8a (soft wrl)
328	Massiness
329	Square
330	Slow Square Lead
331	Sine Solo
332	Square Lead 4
333	Thick Square  2Oscillators Lead
335	Wavy Sawtooth 2
336	Analog Lead
337	Big Lead
338	Fat Lead





339	PWM 4th	395	Warm Air	451	Analog Cymbal
340	'	396	FX 5 (brightness)	452	Ride Cymbal
341	Delayed Lead 2	397	Smog	453	China Cymbal
342	Fifth Lead	398	FX 6 (goblins)	454	Ride Bell
343	Corrie	399	FX 6 (goblins) 2	455	Tambourine
344	Quint	400	Choir Bell	456	Splash Cymbal
Syn	th Pad	401	Choir Bell 2	457	Cowbell
	Pad 1 (new age)	402	FX 7 (echoes)	458	Analog Cowbell
346	Pad 1 (new age) 2	403	FX 7 (echoes) 2	459	High Bongo
347	Pad 2 (warm)	404	FX 7b (echo pan)	460	Low Bongo
348	Pad 2 (warm) 2	405	FX 7a (echo bell)	461	Mute Hi Conga
349	Pad 2a (sine pad)	406	FX 7a (echo bell) 2	462	Open Hi Conga
350	Pad 3 (polysynth)		FX 7a (echo bell) 3	463	Low Conga
351	Pad 3 (polysynth) 2		FX 8 (sci-fi)	464	Analog Hi Conga
352	Pad 3 (polysynth) 3		FX 8 (sci-fi) 2	465	Analog Mid Conga
353	Pad 3 (polysynth) 4		nic Misc.	466	Analog Low Conga
354	Pad 4 (choir)		Sitar	467	High Timbale
355		411	Sitar 2	468	Low Timbale
	Pad 4 (choir) 2				
356	Pad 4a (itopia)	412	Banjo	469	Cabasa
357	Pad 5 (bowed)	413	Banjo 2	470	Maracas
358	Pad 5 (bowed) 2	414	Shamisen	471	Analog Maracas
359	Pad 6 (metallic)	415	Shamisen 2	472	Short Guiro
360	Pad 6 (metallic) 2	416	Koto	473	Long Guiro
361	Pad 7 (halo)	417	Koto 2	474	Claves
362	Pad 7 (halo) 2	418	Taisho Koto	475	Mute Cuica
363	Pad 8 (sweep)	419	Kalimba	476	Open Cuica
364	Pad 8 (sweep) 2	420	Kalimba 2	477	Mute Triangle
365	Pad 8 (sweep) 3	421	Bag Pipe	478	Open Triangle
366	Pan Pad	422	Bag Pipe 2	479	Shaker
007	D D10	423	Cidalla.	480	Mute Surdo
367	Pan Pad 2	423	Fiddle	700	Widte Suldo
367	Dipolar Pad	424	Fiddle 2	481	Open Surdo
368	Dipolar Pad	424	Fiddle 2	481	Open Surdo
368 369	Dipolar Pad PWM Pad	424 425 426	Fiddle 2 Fiddle 3	481 482	Open Surdo Melodic Tom
368 369 370	Dipolar Pad PWM Pad Warmly Pad	424 425 426 427	Fiddle 2 Fiddle 3 Shanai	481 482 483	Open Surdo Melodic Tom Melodic Tom 2
368 369 370 371	Dipolar Pad PWM Pad Warmly Pad Horn Pad	424 425 426 427	Fiddle 2 Fiddle 3 Shanai Shanai 2	481 482 483 484	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum
368 369 370 371 372 373	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad	424 425 426 427 <b>Perc</b>	Fiddle 2 Fiddle 3 Shanai Shanai 2 cussive	481 482 483 484 485	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum
368 369 370 371 372 373 374	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad	424 425 426 427 <b>Perc</b> 428 429	Fiddle 2 Fiddle 3 Shanai Shanai 2 cussive Tinkle Bell	481 482 483 484 485 486 487	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom
368 369 370 371 372 373 374 375	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft	424 425 426 427 <b>Perc</b> 428 429	Fiddle 2 Fiddle 3 Shanai Shanai 2  Cussive Tinkle Bell Agogo Steel Drums	481 482 483 484 485 486 487 <b>SFX</b>	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal
368 369 370 371 372 373 374 375 376	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad	424 425 426 427 <b>Pero</b> 428 429 430 431	Fiddle 2 Fiddle 3 Shanai Shanai 2 cussive Tinkle Bell Agogo	481 482 483 484 485 486 487 <b>SFX</b>	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal Guitar Fret Noise
368 369 370 371 372 373 374 375 376	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox	424 425 426 427 <b>Perc</b> 428 429 430 431 432	Fiddle 2 Fiddle 3 Shanai Shanai 2 Eussive Tinkle Bell Agogo Steel Drums Woodblock Castanets	481 482 483 484 485 486 487 <b>SFX</b> 488	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise
368 369 370 371 372 373 374 375 376 377	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox 5th SawWave	424 425 426 427 <b>Perc</b> 428 429 430 431 432	Fiddle 2 Fiddle 3 Shanai Shanai 2 cussive Tinkle Bell Agogo Steel Drums Woodblock Castanets Taiko Drum	481 482 483 484 485 486 487 <b>SFX</b> 488 489	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise Acoustic Bass String Slap
368 369 370 371 372 373 374 375 376 377 378	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox 5th SawWave 5th Lead Soft	424 425 426 427 <b>Perc</b> 428 429 430 431 432 433	Fiddle 2 Fiddle 3 Shanai Shanai 2 Cussive Tinkle Bell Agogo Steel Drums Woodblock Castanets Taiko Drum Concert Bass Drum	481 482 483 484 485 486 487 <b>SFX</b> 488 489 490	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise Acoustic Bass String Slap Breath Noise
368 369 370 371 372 373 374 375 376 377 378 379 380	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox 5th SawWave 5th Lead Soft Slow Square	424 425 426 427 <b>Pero</b> 428 429 430 431 432 433 434	Fiddle 2 Fiddle 3 Shanai Shanai 2 Cussive Tinkle Bell Agogo Steel Drums Woodblock Castanets Taiko Drum Concert Bass Drum Acoustic Bass Drum	481 482 483 484 485 486 487 <b>SFX</b> 488 489 490 491	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise Acoustic Bass String Slap Breath Noise Flute Key Click
368 369 370 371 372 373 374 375 376 377 378 379 380 381	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox 5th SawWave 5th Lead Soft Slow Square New Year Pad	424 425 426 427 <b>Per</b> 428 429 430 431 432 433 434 435	Fiddle 2 Fiddle 3 Shanai Shanai 2  Cussive Tinkle Bell Agogo Steel Drums Woodblock Castanets Taiko Drum Concert Bass Drum Acoustic Bass Drum Jazz Kick	481 482 483 484 485 486 487 <b>SFX</b> 488 489 490 491 492	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise Acoustic Bass String Slap Breath Noise Flute Key Click Seashore
368 369 370 371 372 373 374 375 376 377 378 380 381 382	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox 5th SawWave 5th Lead Soft Slow Square New Year Pad Space Voice	424 425 426 427 Perc 428 429 430 431 432 433 434 435 436 437	Fiddle 2 Fiddle 3 Shanai Shanai 2  Cussive Tinkle Bell Agogo Steel Drums Woodblock Castanets Taiko Drum Concert Bass Drum Acoustic Bass Drum Jazz Kick Side Stick	481 482 483 484 485 486 487 <b>SFX</b> 488 489 490 491 492 493	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise Acoustic Bass String Slap Breath Noise Flute Key Click Seashore Rain
368 369 370 371 372 373 374 375 376 377 378 380 381 382 383	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox 5th SawWave 5th Lead Soft Slow Square New Year Pad Space Voice Rising	424 425 426 427 Perc 428 429 430 431 432 433 434 435 436 437	Fiddle 2 Fiddle 3 Shanai Shanai 2 Sussive Tinkle Bell Agogo Steel Drums Woodblock Castanets Taiko Drum Concert Bass Drum Acoustic Bass Drum Jazz Kick Side Stick Analog Rim Shot	481 482 483 484 485 486 487 <b>SFX</b> 488 489 490 491 492 493 494	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise Acoustic Bass String Slap Breath Noise Flute Key Click Seashore Rain Thunder
368 369 370 371 372 373 374 375 376 377 380 381 382 383 384	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox 5th SawWave 5th Lead Soft Slow Square New Year Pad Space Voice Rising Congregate	424 425 426 427 Perc 428 429 430 431 432 433 434 435 436 437 438 439	Fiddle 2 Fiddle 3 Shanai Shanai 2 Sussive Tinkle Bell Agogo Steel Drums Woodblock Castanets Taiko Drum Concert Bass Drum Acoustic Bass Drum Jazz Kick Side Stick Analog Rim Shot Acoustic Snare	481 482 483 484 485 486 487 <b>SFX</b> 488 489 490 491 492 493 494 495	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise Acoustic Bass String Slap Breath Noise Flute Key Click Seashore Rain Thunder Wind
368 369 370 371 372 373 374 375 376 377 380 381 382 383 384 <b>Syn</b>	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox 5th SawWave 5th Lead Soft Slow Square New Year Pad Space Voice Rising Congregate th SFX	424 425 426 427 Perc 428 429 430 431 432 433 434 435 436 437 438 439 440	Fiddle 2 Fiddle 3 Shanai Shanai 2 Sussive Tinkle Bell Agogo Steel Drums Woodblock Castanets Taiko Drum Concert Bass Drum Acoustic Bass Drum Jazz Kick Side Stick Analog Rim Shot Acoustic Snare Jazz Snare	481 482 483 484 485 486 487 <b>SFX</b> 488 489 490 491 492 493 494 495 496 497	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise Acoustic Bass String Slap Breath Noise Flute Key Click Seashore Rain Thunder Wind Stream
368 369 370 371 372 373 374 375 376 377 380 381 382 383 384 <b>Syn</b>	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox 5th SawWave 5th Lead Soft Slow Square New Year Pad Space Voice Rising Congregate th SFX FX 1 (rain)	424 425 426 427 Perc 428 429 430 431 432 433 434 435 436 437 438 439 440	Fiddle 2 Fiddle 3 Shanai Shanai 2 Eussive Tinkle Bell Agogo Steel Drums Woodblock Castanets Taiko Drum Concert Bass Drum Acoustic Bass Drum Jazz Kick Side Stick Analog Rim Shot Acoustic Snare Jazz Snare Brush Tap	481 482 483 484 485 486 487 <b>SFX</b> 488 489 490 491 492 493 494 495 496 497 498	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise Acoustic Bass String Slap Breath Noise Flute Key Click Seashore Rain Thunder Wind Stream Bubble
368 369 370 371 372 373 374 375 376 377 380 381 382 383 384 <b>Syn</b> 385 386	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox 5th SawWave 5th Lead Soft Slow Square New Year Pad Space Voice Rising Congregate th SFX FX 1 (rain) FX 1 (rain) 2	424 425 426 427 Pere 428 429 430 431 432 433 434 435 436 437 438 439 440 441	Fiddle 2 Fiddle 3 Shanai Shanai 2 Eussive Tinkle Bell Agogo Steel Drums Woodblock Castanets Taiko Drum Concert Bass Drum Acoustic Bass Drum Jazz Kick Side Stick Analog Rim Shot Acoustic Snare Jazz Snare Brush Tap Concert SD	481 482 483 484 485 486 487 <b>SFX</b> 488 489 490 491 492 493 494 495 496 497 498	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise Acoustic Bass String Slap Breath Noise Flute Key Click Seashore Rain Thunder Wind Stream Bubble Bird Tweet
368 369 370 371 372 373 374 375 376 377 380 381 382 383 384 <b>Syn</b> 385 386 387	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox 5th SawWave 5th Lead Soft Slow Square New Year Pad Space Voice Rising Congregate th SFX FX 1 (rain) FX 1 (rain) 2 FX 2 (soundtrack)	424 425 426 427 Pere 428 429 430 431 432 433 434 435 436 437 438 440 441 442 443	Fiddle 2 Fiddle 3 Shanai Shanai 2 Cussive Tinkle Bell Agogo Steel Drums Woodblock Castanets Taiko Drum Concert Bass Drum Acoustic Bass Drum Jazz Kick Side Stick Analog Rim Shot Acoustic Snare Jazz Snare Brush Tap Concert SD Hand Clap	481 482 483 484 485 486 487 <b>SFX</b> 488 489 490 491 492 493 494 495 496 497 498 499 500	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise Acoustic Bass String Slap Breath Noise Flute Key Click Seashore Rain Thunder Wind Stream Bubble Bird Tweet Bird Tweet 2
368 369 370 371 372 373 374 375 376 379 380 381 382 383 384 <b>Syn</b> 385 386 387 388	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox 5th SawWave 5th Lead Soft Slow Square New Year Pad Space Voice Rising Congregate th SFX FX 1 (rain) FX 1 (rain) 2 FX 2 (soundtrack) FX 2 (soundtrack)	424 425 426 427 Pere 428 429 430 431 432 433 434 435 436 437 438 439 440 441 442 443 444	Fiddle 2 Fiddle 3 Shanai Shanai 2 Eussive Tinkle Bell Agogo Steel Drums Woodblock Castanets Taiko Drum Concert Bass Drum Acoustic Bass Drum Jazz Kick Side Stick Analog Rim Shot Acoustic Snare Jazz Snare Brush Tap Concert SD Hand Clap Tom	481 482 483 484 485 486 487 <b>SFX</b> 488 489 490 491 492 493 494 495 496 497 498 499 500 501	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise Acoustic Bass String Slap Breath Noise Flute Key Click Seashore Rain Thunder Wind Stream Bubble Bird Tweet Bird Tweet 2 Dog
368 369 370 371 372 373 374 375 376 377 380 381 382 383 384 <b>Syn</b> 385 386 387 388 388 388	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox 5th SawWave 5th Lead Soft Slow Square New Year Pad Space Voice Rising Congregate th SFX FX 1 (rain) FX 2 (soundtrack) FX 2 (soundtrack) FX 2 (soundtrack) Prelude	424 425 426 427 Pere 428 429 430 431 432 433 434 435 436 437 438 439 440 441 442 443 444	Fiddle 2 Fiddle 3 Shanai Shanai 2 Eussive Tinkle Bell Agogo Steel Drums Woodblock Castanets Taiko Drum Concert Bass Drum Acoustic Bass Drum Jazz Kick Side Stick Analog Rim Shot Acoustic Snare Jazz Snare Brush Tap Concert SD Hand Clap Tom Brush Tom	481 482 483 484 485 486 487 <b>SFX</b> 488 489 490 491 492 493 494 495 496 497 498 499 500 501 502	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise Acoustic Bass String Slap Breath Noise Flute Key Click Seashore Rain Thunder Wind Stream Bubble Bird Tweet Bird Tweet 2 Dog Horse Gallop
368 369 370 371 372 373 374 375 376 377 380 381 382 383 384 <b>Syn</b> 385 386 387 388 389 390	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox 5th SawWave 5th Lead Soft Slow Square New Year Pad Space Voice Rising Congregate th SFX FX 1 (rain) FX 2 (soundtrack) FX 2 (soundtrack) FX 3 (crystal)	424 425 426 427 Perc 428 429 430 431 432 433 434 435 436 437 438 439 440 441 442 443 444 445	Fiddle 2 Fiddle 3 Shanai Shanai 2  Eussive Tinkle Bell Agogo Steel Drums Woodblock Castanets Taiko Drum Concert Bass Drum Acoustic Bass Drum Jazz Kick Side Stick Analog Rim Shot Acoustic Snare Jazz Snare Brush Tap Concert SD Hand Clap Tom Brush Tom Closed Hi-hat	481 482 483 484 485 486 487 <b>SFX</b> 488 489 490 491 492 493 494 495 496 497 498 499 500 501 502 503	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise Acoustic Bass String Slap Breath Noise Flute Key Click Seashore Rain Thunder Wind Stream Bubble Bird Tweet Bird Tweet 2 Dog Horse Gallop Telephone Ring
368 369 370 371 372 373 374 375 376 377 380 381 382 383 384 <b>Synn</b> 385 386 387 388 389 391	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox 5th SawWave 5th Lead Soft Slow Square New Year Pad Space Voice Rising Congregate th SFX FX 1 (rain) FX 1 (rain) 2 FX 2 (soundtrack) FX 2 (soundtrack) 2 Prelude FX 3 (crystal) FX 3 (crystal) FX 3 (crystal)	424 425 426 427 Perc 428 429 430 431 432 433 434 435 436 437 438 439 440 441 442 443 444 445 446 447	Fiddle 2 Fiddle 3 Shanai Shanai 2  Eussive  Tinkle Bell Agogo Steel Drums Woodblock Castanets Taiko Drum Concert Bass Drum Acoustic Bass Drum Jazz Kick Side Stick Analog Rim Shot Acoustic Snare Jazz Snare Brush Tap Concert SD Hand Clap Tom Brush Tom Closed Hi-hat Analog Closed Hi-hat	481 482 483 484 485 486 487 <b>SFX</b> 488 489 490 491 492 493 494 495 496 497 498 499 500 501 502 503 504	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise Acoustic Bass String Slap Breath Noise Flute Key Click Seashore Rain Thunder Wind Stream Bubble Bird Tweet Bird Tweet 2 Dog Horse Gallop Telephone Ring Telephone Ring Telephone Ring Telephone Ring Tomm Melodic Tom Accounts Additional Comments  Melodic Tom Bubble Melodic Tom Melodic
368 369 370 371 372 373 374 375 376 377 388 381 382 383 384 <b>Syn</b> 385 386 387 388 389 390 391 392	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox 5th SawWave 5th Lead Soft Slow Square New Year Pad Space Voice Rising Congregate th SFX FX 1 (rain) FX 1 (rain) 2 FX 2 (soundtrack) FX 2 (soundtrack) 2 Prelude FX 3 (crystal) FX 3 (crystal) FX 3 (synth mallet)	424 425 426 427 Perc 428 429 430 431 432 433 434 435 436 437 438 439 440 441 442 443 444 445 446 447	Fiddle 2 Fiddle 3 Shanai Shanai 2  Eussive Tinkle Bell Agogo Steel Drums Woodblock Castanets Taiko Drum Concert Bass Drum Acoustic Bass Drum Jazz Kick Side Stick Analog Rim Shot Acoustic Snare Jazz Snare Brush Tap Concert SD Hand Clap Tom Brush Tom Closed Hi-hat Analog Closed Hi-hat Pedal Hi-hat	481 482 483 484 485 486 487 <b>SFX</b> 488 489 490 491 492 493 494 495 496 497 498 499 500 501 502 503 504 505	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise Acoustic Bass String Slap Breath Noise Flute Key Click Seashore Rain Thunder Wind Stream Bubble Bird Tweet Bird Tweet 2 Dog Horse Gallop Telephone Ring Telephone Ring 2 Door Creaking
368 369 370 371 372 373 374 375 376 377 388 381 382 383 384 <b>Syn</b> 385 386 387 388 389 390 391 392 393	Dipolar Pad PWM Pad Warmly Pad Horn Pad Click Pad Analog Pad 80's Poly Pad PWM 4th Soft Synth Calliope Soft Soft Vox 5th SawWave 5th Lead Soft Slow Square New Year Pad Space Voice Rising Congregate th SFX FX 1 (rain) FX 1 (rain) 2 FX 2 (soundtrack) FX 2 (soundtrack) 2 Prelude FX 3 (crystal) FX 3 (crystal) FX 3 (crystal)	424 425 426 427 Perc 428 429 430 431 432 433 434 435 436 437 438 439 440 441 442 443 444 445 446 447 448	Fiddle 2 Fiddle 3 Shanai Shanai 2  Eussive  Tinkle Bell Agogo Steel Drums Woodblock Castanets Taiko Drum Concert Bass Drum Acoustic Bass Drum Jazz Kick Side Stick Analog Rim Shot Acoustic Snare Jazz Snare Brush Tap Concert SD Hand Clap Tom Brush Tom Closed Hi-hat Analog Closed Hi-hat	481 482 483 484 485 486 487 <b>SFX</b> 488 489 490 491 492 493 494 495 496 497 498 499 500 501 502 503 504	Open Surdo Melodic Tom Melodic Tom 2 Synth Drum Rhythm Box Tom Electric Drum Reverse Cymbal  Guitar Fret Noise Guitar Cutting Noise Acoustic Bass String Slap Breath Noise Flute Key Click Seashore Rain Thunder Wind Stream Bubble Bird Tweet Bird Tweet 2 Dog Horse Gallop Telephone Ring Telephone Ring Telephone Ring Telephone Ring Tomm Melodic Tom Accounts Additional Comments  Melodic Tom Bubble Melodic Tom Melodic













508	Wind Chime		
509	Helicopter		
510	Car Engine		
511	Car Stop		
512	Car Pass		
513	Car Crash		
514	Siren		
515	Train		
516	Jetplane		
517	Starship		
518	Burst Noise		
519	Applause		
520	Laughing		
521	Screaming		
522	Punch		
523	Heart Beat		
524	Footsteps		
525	Gunshot		
526	Machine Gun		
527	Lasergun		
528	Explosion		
	ined Voice		
529	Stereo Piano & Strings Pad		
530	Stereo Piano & Choir		
531	Stereo Piano & Synth Strings		
532	Stereo Piano & Warm Pad		
533	Stereo Piano & Soft EP		
534	FM Electric Piano		
535	Digital Piano		
536	E.Piano & Strings		
537	E.Piano & Acoustic Guitar		
538	E.Piano & Vibraphone		
539	E.Piano 2 & Pad		
540	E.Piano 2 & Strings		
541	Harpsichord & Stereo Strings		
542	Music Box & Stereo Strings		
543	Vibraphone & Stereo Strings		
544	Vibraphone Octave		
545	Vibraphone & Marimba & Kalimba		
546	Marimba & Kalimba		
547	Marimba Delay		
548	Xylophone Octave		
549	Organ & Stereo Strings		
550	Stereo Organ & Piano		
551	Rock Organ & Strings		
552	Church Organ & Choir		
553	Church Organ & Strings		
554	Acoustic Guitar & Flute		
555	Acoustic Guitar & Clavi		
556	24 String Guitar		
557	Steel Guitar & Warm Pad		
558	Stereo Strings & Horn		
559	Orchestra		
560	Full Strings		
561	Full Strings 2		
562	Symphonic		
563	Stereo Choir & Strings		
564	Stereo Choir & Steel Guitar		

565	3 Trumpet Loose
566	Trombone & Stereo Strings
567	3 Trombones Loose
568	3 Muted Trumpets Loose
569	Club Brass
570	Brass & Woodwinds
571	Woodwinds & Strings
572	Section Woods Small
573	Pan Flute & Strings Pad
574	Koto & Shamisen
575	Flute & Clarinet
576	Flute & Oboe
577	Flute & Bassoon
578	Flute & Oboe & Clarinet
579	Flute & Clarinet & Bassoon
580	Flute & Oboe & Bassoon
581	Flute Octave
582	Flute & Oboe Octave
583	Flute & Clarinet Octave
584	Oboe & Bassoon
585	Oboe & Clarinet
586	Oboe & Clarinet & Bassoon
587	Oboe Octave
588	Oboe & Clarinet Octave
589	Oboe & Bassoon Octave
590	Clarinet & Bassoon
591	Clarinet & Oboe Octave
Drums	3
592	Standard Set
593	Room Set
594	Power Set
595	Electronic Set
596	Analog Set
597	Jazz Set
598	Brush Set
599	Orchestra Set
600	SFX Set











# Style List

8 BEAT  1	NO IN.					
1 8Beat Ballad 2 8Beat Piano 3 8Beat 1 4 Guitar Pop 1 5 8Beat Hip Hop 6 8Beat Blues Rock 7 8Beat Pop 8 Pop Funk 1 9 Rhythm&Beat 1 10 8Beat Disco 1 11 8Beat Rock 12 Guitar Pop 2 13 8Beat 2 14 Sweet Beat 15 8Beat Dance 16 8Beat Disco 2 17 Pop Funk 2 18 8Beat 3 19 60's 8Beat 20 Rhythm&Beat 2 16 BEAT 21 16Beat 1 22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat 7 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 4 32 Modern 16Beat 3 33 16Beat Ballad 2 39 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat	NO.	Name				
2 8Beat Piano 3 8Beat 1 4 Guitar Pop 1 5 8Beat Hip Hop 6 8Beat Blues Rock 7 8Beat Pop 8 Pop Funk 1 9 Rhythm&Beat 1 10 8Beat Disco 1 11 8Beat Rock 12 Guitar Pop 2 13 8Beat 2 14 Sweet Beat 15 8Beat Dance 16 8Beat Disco 2 17 Pop Funk 2 18 8Beat 3 19 60's 8Beat 20 Rhythm&Beat 2 16 BEAT 21 16Beat 1 22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Punk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Modern 35 16Beat A 36 16Beat A 37 Cool Beat 38 16Beat A 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 2 48 Pop 16Beat 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat	_					
3 8Beat 1 4 Guitar Pop 1 5 8Beat Hip Hop 6 8Beat Blues Rock 7 8Beat Pop 8 Pop Funk 1 9 Rhythm&Beat 1 10 8Beat Disco 1 11 8Beat Rock 12 Guitar Pop 2 13 8Beat 2 14 Sweet Beat 15 8Beat Dance 16 8Beat Disco 2 17 Pop Funk 2 18 8Beat 3 19 60's 8Beat 20 Rhythm&Beat 2 16 BEAT 21 16Beat 1 22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat ABB 35 16Beat Funk 3 36 16Beat ABB 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
4 Guitar Pop 1 5 8Beat Hip Hop 6 8Beat Blues Rock 7 8Beat Pop 8 Pop Funk 1 9 Rhythm&Beat 1 10 8Beat Disco 1 11 8Beat Rock 12 Guitar Pop 2 13 8Beat 2 14 Sweet Beat 15 8Beat Dance 16 8Beat Disco 2 17 Pop Funk 2 18 8Beat 3 19 60's 8Beat 20 Rhythm&Beat 2 16 BEAT 21 16Beat 1 22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Ballad 2 39 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
5 8Beat Hip Hop 6 8Beat Blues Rock 7 8Beat Pop 8 Pop Funk 1 9 Rhythm&Beat 1 10 8Beat Disco 1 11 8Beat Rock 12 Guitar Pop 2 13 8Beat 2 14 Sweet Beat 15 8Beat Dance 16 8Beat Disco 2 17 Pop Funk 2 18 8Beat 3 19 60's 8Beat 20 Rhythm&Beat 2 16 BEAT 21 16Beat 1 22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat 7 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
6 8Beat Blues Rock 7 8Beat Pop 8 Pop Funk 1 9 Rhythm&Beat 1 10 8Beat Disco 1 11 8Beat Rock 12 Guitar Pop 2 13 8Beat 2 14 Sweet Beat 15 8Beat Dance 16 8Beat Disco 2 17 Pop Funk 2 18 8Beat 3 19 60's 8Beat 20 Rhythm&Beat 2 16Beat T 21 16Beat 1 22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat Funk 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
7         8Beat Pop           8         Pop Funk 1           9         Rhythm&Beat 1           10         8Beat Disco 1           11         8Beat Rock           12         Guitar Pop 2           13         8Beat 2           14         Sweet Beat           15         8Beat Dance           16         8Beat Disco 2           17         Pop Funk 2           18         8Beat Disco 2           17         Pop Funk 2           18         8Beat Disco 2           17         Pop Funk 2           18         8Beat Disco 2           19         60's 8Beat           20         Rhythm&Beat 2           16         BEAT           21         16Beat 1           22         16Beat Ballad 1           24         16Beat Ballad 1           24         16Beat Punk 2           27         16Beat Dance           28         Pop 16Beat 2           30         Pop 16Beat 3           31         Pop 16Beat 4           32         Modern 16Beat           33         16Beat Funk 3           36         16Beat Ballad 2						
8  Pop Funk 1 9  Rhythm&Beat 1 10  8Beat Disco 1 11  8Beat Rock 12  Guitar Pop 2 13  8Beat 2 14  Sweet Beat 15  8Beat Dance 16  8Beat Disco 2 17  Pop Funk 2 18  8Beat 3 19  60's 8Beat 20  Rhythm&Beat 2 16  8EAT 21  16Beat 1 22  16Beat Funk 1 23  16Beat Ballad 1 24  16Beat R&B 25  Pop 16Beat 1 26  16Beat Funk 2 27  16Beat Dance 28  Pop 16Beat 2 29  16Beat 2 30  Pop 16Beat 3 31  Pop 16Beat 3 31  Pop 16Beat 4 32  Modern 16Beat 33  16Beat Hot 34  16Beat Modern 35  16Beat Funk 3 36  16Beat 3 37  Cool Beat 38  16Beat Ballad 2 39  16Beat 4 40  Pop Shuffle POP & BALLAD 41  Pop Rock 1 42  Pop Dance 1 43  Pop Fusion 44  Analog Night 1 45  6/8 Pop 46  Brit. Pop 2 48  Pop Hit 49  Fusion Shuffle 50  Analog Night 2 51  Guitar Pop 3 52  Pop Beat 53  Soft Beat						
9 Rhythm&Beat 1 10 8Beat Disco 1 11 8Beat Rock 12 Guitar Pop 2 13 8Beat 2 14 Sweet Beat 15 8Beat Dance 16 8Beat Disco 2 17 Pop Funk 2 18 8Beat 3 19 60's 8Beat 20 Rhythm&Beat 2 16 BEAT 21 16Beat 1 22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat		•				
10 8Beat Disco 1 11 8Beat Rock 12 Guitar Pop 2 13 8Beat 2 14 Sweet Beat 15 8Beat Dance 16 8Beat Disco 2 17 Pop Funk 2 18 8Beat 3 19 60's 8Beat 20 Rhythm&Beat 2 16Beat Funk 1 22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 2 29 16Beat 3 31 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat Funk 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat		-				
11 8Beat Rock 12 Guitar Pop 2 13 8Beat 2 14 Sweet Beat 15 8Beat Dance 16 8Beat Disco 2 17 Pop Funk 2 18 8Beat 3 19 60's 8Beat 20 Rhythm&Beat 2 16Beat Funk 1 22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat Funk 3 36 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat		,				
12 Guitar Pop 2 13 8Beat 2 14 Sweet Beat 15 8Beat Dance 16 8Beat Disco 2 17 Pop Funk 2 18 8Beat 3 19 60's 8Beat 20 Rhythm&Beat 2 16 BEAT 21 16Beat 1 22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat Funk 3 36 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
13 8Beat 2 14 Sweet Beat 15 8Beat Dance 16 8Beat Disco 2 17 Pop Funk 2 18 8Beat 3 19 60's 8Beat 20 Rhythm&Beat 2 16 BEAT 21 16Beat T 21 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
14 Sweet Beat 15 8Beat Dance 16 8Beat Disco 2 17 Pop Funk 2 18 8Beat 3 19 60's 8Beat 20 Rhythm&Beat 2 16 BEAT 21 16Beat T 21 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat		·				
15 8Beat Dance 16 8Beat Disco 2 17 Pop Funk 2 18 8Beat 3 19 60's 8Beat 20 Rhythm&Beat 2 16 BEAT 21 16Beat 1 22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
16 8Beat Disco 2 17 Pop Funk 2 18 8Beat 3 19 60's 8Beat 20 Rhythm&Beat 2 16 BEAT 21 16Beat 1 22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
17 Pop Funk 2 18 8Beat 3 19 60's 8Beat 20 Rhythm&Beat 2 16 BEAT 21 16Beat 1 22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
18 8Beat 3 19 60's 8Beat 20 Rhythm&Beat 2 16 BEAT 21 16Beat 1 22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Funk 3 36 16Beat Funk 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
19 60's 8Beat 20 Rhythm&Beat 2  16 BEAT 21 16Beat T 22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat		'				
20 Rhythm&Beat 2  16 BEAT  21 16Beat 1  22 16Beat Funk 1  23 16Beat Ballad 1  24 16Beat R&B  25 Pop 16Beat 1  26 16Beat Funk 2  27 16Beat Dance  28 Pop 16Beat 2  29 16Beat 2  30 Pop 16Beat 3  31 Pop 16Beat 4  32 Modern 16Beat  33 16Beat Hot  34 16Beat Modern  35 16Beat Funk 3  36 16Beat 3  37 Cool Beat  38 16Beat Ballad 2  39 16Beat 4  40 Pop Shuffle  POP & BALLAD  41 Pop Rock 1  42 Pop Dance 1  43 Pop Fusion  44 Analog Night 1  45 6/8 Pop  46 Brit. Pop 1  47 Brit. Pop 2  48 Pop Hit  49 Fusion Shuffle  50 Analog Night 2  51 Guitar Pop 3  52 Pop Beat  53 Soft Beat						
21 16Beat 1 22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Funk 3 36 16Beat Funk 3 36 16Beat Funk 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
21 16Beat 1 22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat	_	,				
22 16Beat Funk 1 23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
23 16Beat Ballad 1 24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat Funk 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
24 16Beat R&B 25 Pop 16Beat 1 26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat Funk 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat	-					
25  Pop 16Beat 1 26  16Beat Funk 2 27  16Beat Dance 28  Pop 16Beat 2 29  16Beat 2 30  Pop 16Beat 3 31  Pop 16Beat 4 32  Modern 16Beat 33  16Beat Hot 34  16Beat Modern 35  16Beat Funk 3 36  16Beat Funk 3 37  Cool Beat 38  16Beat Ballad 2 39  16Beat 4 40  Pop Shuffle POP & BALLAD 41  Pop Rock 1 42  Pop Dance 1 43  Pop Fusion 44  Analog Night 1 45  6/8 Pop 46  Brit. Pop 1 47  Brit. Pop 2 48  Pop Hit 49  Fusion Shuffle 50  Analog Night 2 51  Guitar Pop 3 52  Pop Beat 53  Soft Beat						
26 16Beat Funk 2 27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Hot 35 16Beat Funk 3 36 16Beat Funk 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
27 16Beat Dance 28 Pop 16Beat 2 29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat		'				
28  Pop 16Beat 2 29  16Beat 2 30  Pop 16Beat 3 31  Pop 16Beat 4 32  Modern 16Beat 33  16Beat Hot 34  16Beat Modern 35  16Beat Funk 3 36  16Beat 3 37  Cool Beat 38  16Beat Ballad 2 39  16Beat 4 40  Pop Shuffle POP & BALLAD 41  Pop Rock 1 42  Pop Dance 1 43  Pop Fusion 44  Analog Night 1 45  6/8 Pop 46  Brit. Pop 1 47  Brit. Pop 2 48  Pop Hit 49  Fusion Shuffle 50  Analog Night 2 51  Guitar Pop 3 52  Pop Beat 53  Soft Beat	_					
29 16Beat 2 30 Pop 16Beat 3 31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
30  Pop 16Beat 3 31  Pop 16Beat 4 32  Modern 16Beat 33  16Beat Hot 34  16Beat Modern 35  16Beat Funk 3 36  16Beat 3 37  Cool Beat 38  16Beat Ballad 2 39  16Beat 4 40  Pop Shuffle  POP & BALLAD 41  Pop Rock 1 42  Pop Dance 1 43  Pop Fusion 44  Analog Night 1 45  6/8 Pop 46  Brit. Pop 1 47  Brit. Pop 2 48  Pop Hit 49  Fusion Shuffle 50  Analog Night 2 51  Guitar Pop 3 52  Pop Beat 53  Soft Beat	_	'				
31 Pop 16Beat 4 32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
32 Modern 16Beat 33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle  POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat		•				
33 16Beat Hot 34 16Beat Modern 35 16Beat Funk 3 36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle  POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat		· ·				
34 16Beat Modern 35 16Beat Funk 3 36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle  POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
35 16Beat Funk 3 36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle  POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
36 16Beat 3 37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
37 Cool Beat 38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle  POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
38 16Beat Ballad 2 39 16Beat 4 40 Pop Shuffle  POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
39 16Beat 4 40 Pop Shuffle POP & BALLAD 41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
40 Pop Shuffle  POP & BALLAD  41 Pop Rock 1  42 Pop Dance 1  43 Pop Fusion  44 Analog Night 1  45 6/8 Pop  46 Brit. Pop 1  47 Brit. Pop 2  48 Pop Hit  49 Fusion Shuffle  50 Analog Night 2  51 Guitar Pop 3  52 Pop Beat  53 Soft Beat						
POP & BALLAD  41 Pop Rock 1  42 Pop Dance 1  43 Pop Fusion  44 Analog Night 1  45 6/8 Pop  46 Brit. Pop 1  47 Brit. Pop 2  48 Pop Hit  49 Fusion Shuffle  50 Analog Night 2  51 Guitar Pop 3  52 Pop Beat  53 Soft Beat						
41 Pop Rock 1 42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat		<u>'</u>				
42 Pop Dance 1 43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
43 Pop Fusion 44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat		'				
44 Analog Night 1 45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat		•				
45 6/8 Pop 46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
46 Brit. Pop 1 47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
47 Brit. Pop 2 48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat		· · · · · · · · · · · · · · · · · · ·				
48 Pop Hit 49 Fusion Shuffle 50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat						
<ul> <li>49 Fusion Shuffle</li> <li>50 Analog Night 2</li> <li>51 Guitar Pop 3</li> <li>52 Pop Beat</li> <li>53 Soft Beat</li> </ul>		'				
50 Analog Night 2 51 Guitar Pop 3 52 Pop Beat 53 Soft Beat	48	· · · · · · · · · · · · · · · · · · ·				
51 Guitar Pop 3 52 Pop Beat 53 Soft Beat	49					
52 Pop Beat 53 Soft Beat						
53 Soft Beat	51	Guitar Pop 3				
	52	Pop Beat				
54   60's Pop	53					
	54	60's Pop				

55	Sting Latin			
56	R&B Ballad 1			
57	Guitar Ballad			
58	Ballad Rock			
59	Piano Pop			
60	Soft Ballad			
61	Natural Ballad			
62	Love Ballad			
63	Easy Ballad			
64	Miami Folk			
65	Slow Ballad			
66	Folk Ballad			
67	Pop Ballad 1			
68	Pop Ballad 2			
69	EP Ballad			
70	New R&B Ballad			
_				
ROC				
71	Rock			
72	New Wave			
73	Ska			
74	Pop Rock 2			
75	Slow Rock			
76	70's Rock&Roll			
77	Folk Rock			
78	Soft Rock			
79	Old Rock			
80	Easy Rock			
81	New Shuffle			
82	Rock Hip Hop			
83	Rock&Roll 1			
84	Rock Shuffle			
85	Rock&Roll 2			
BALI	LROOM			
86	Tango 1			
87	Spain Matador			
88	Twist 1			
89	Twist 2			
90	Die Dand Carr			
91	Big Band Fox			
	0			
92	Tango 2			
_	Tango 2 Slow Fox			
92	Tango 2 Slow Fox Slow Waltz 1			
92 93	Tango 2 Slow Fox			
92 93 94	Tango 2 Slow Fox Slow Waltz 1 Swing Fox			
92 93 94 95	Tango 2 Slow Fox Slow Waltz 1 Swing Fox Salsa 1 Cha Cha 1			
92 93 94 95 96 97	Tango 2 Slow Fox Slow Waltz 1 Swing Fox Salsa 1 Cha Cha 1 Cha Cha 2			
92 93 94 95 96 97 98	Tango 2 Slow Fox Slow Waltz 1 Swing Fox Salsa 1 Cha Cha 1 Cha Cha 2 Beguine 1			
92 93 94 95 96 97 98 99	Tango 2 Slow Fox Slow Waltz 1 Swing Fox Salsa 1 Cha Cha 1 Cha Cha 2 Beguine 1 Beguine 2			
92 93 94 95 96 97 98 99	Tango 2 Slow Fox Slow Waltz 1 Swing Fox Salsa 1 Cha Cha 1 Cha Cha 2 Beguine 1 Beguine 2 Rumba 1			
92 93 94 95 96 97 98 99 100	Tango 2 Slow Fox Slow Waltz 1 Swing Fox Salsa 1 Cha Cha 1 Cha Cha 2 Beguine 1 Beguine 2 Rumba 1 Samba 1			
92 93 94 95 96 97 98 99 100 101	Tango 2 Slow Fox Slow Waltz 1 Swing Fox Salsa 1 Cha Cha 1 Cha Cha 2 Beguine 1 Beguine 2 Rumba 1 Samba 1 Samba 2			
92 93 94 95 96 97 98 99 100 101 102 103	Tango 2 Slow Fox Slow Waltz 1 Swing Fox Salsa 1 Cha Cha 1 Cha Cha 2 Beguine 1 Beguine 2 Rumba 1 Samba 1 Samba 2 Jive			
92 93 94 95 96 97 98 99 100 101 102 103 104	Tango 2 Slow Fox Slow Waltz 1 Swing Fox Salsa 1 Cha Cha 1 Cha Cha 2 Beguine 1 Beguine 2 Rumba 1 Samba 1 Samba 2 Jive Fox Trot			
92 93 94 95 96 97 98 99 100 101 102 103 104 <b>DAN</b>	Tango 2 Slow Fox Slow Waltz 1 Swing Fox Salsa 1 Cha Cha 1 Cha Cha 2 Beguine 1 Beguine 2 Rumba 1 Samba 1 Samba 2 Jive Fox Trot			
92 93 94 95 96 97 98 99 100 101 102 103 104 <b>DAN</b>	Tango 2 Slow Fox Slow Waltz 1 Swing Fox Salsa 1 Cha Cha 1 Cha Cha 2 Beguine 1 Beguine 2 Rumba 1 Samba 1 Samba 2 Jive Fox Trot CE			
92 93 94 95 96 97 98 99 100 101 102 103 104 <b>DAN</b> 105	Tango 2 Slow Fox Slow Waltz 1 Swing Fox Salsa 1 Cha Cha 1 Cha Cha 2 Beguine 1 Beguine 2 Rumba 1 Samba 1 Samba 2 Jive Fox Trot CE Techno 1 Hip Hop 1			
92 93 94 95 96 97 98 99 100 101 102 103 104 <b>DAN</b> 105 106	Tango 2 Slow Fox Slow Waltz 1 Swing Fox Salsa 1 Cha Cha 1 Cha Cha 2 Beguine 1 Beguine 2 Rumba 1 Samba 1 Samba 2 Jive Fox Trot  CE Techno 1 Hip Hop 1 House 1			
92 93 94 95 96 97 98 99 100 101 102 103 104 <b>DAN</b> 105	Tango 2 Slow Fox Slow Waltz 1 Swing Fox Salsa 1 Cha Cha 1 Cha Cha 2 Beguine 1 Beguine 2 Rumba 1 Samba 1 Samba 2 Jive Fox Trot CE Techno 1 Hip Hop 1			

110	Rap 1		
111	Disco		
112	Soft Disco		
113	70's Disco		
114	Club Dance		
115	Euro Dance		
116	Garage		
SOUL	_ & FUNK		
117	Funk 1		
118	Classic Funk		
119	Jay R&B		
120	Gospel Swing		
121	Gospel		
122	Funk 2		
123	Electric Funk		
124	Groove Funk		
125	Rubber Funk		
126	Cool Funky		
127	Jazz Funk		
128	Groove		
129	Soul		
130	Hip Hop Soul		
131	Hip Hop Beat		
132	R&B		
133	Soul Beat		
134	British Soul Pop		
135	Latin Jazz 1		
136	Big Band 1		
137	Dixieland 1		
138	Guitar Swing 1		
139	Broadway Big Band		
140	Swing		
141	Latin Jazz 2		
142	Fusion		
143	Acid Jazz		
144	Cool Jazz Ballad		
145	Swing Shuffle		
146	Big Band Medium		
147	Dixieland 2		
148	Acoustic Jazz		
149	Guitar Swing 2		
150	Ragtime		
151	Modern Jazz Ballad		
152	Swing Ballad		
153	Orchestra Swing		
	NTRY		
154	Country Pop 1		
155	Bluegrass 1		
156	8Beat Country		
157	Modern Country		
158	Country Pop 2		
159	Bluegrass 2		
160	2/4 Country		
161	Country Quick Steps		
162	Country Folk		
163	Country Shuffle		
	N&LATIN DANCE		
164	Samba 3		











### Style List

165	Bossa Nova			
166	Latin			
167	New Reggae			
168	Reggae Dance			
169	Paso Doble			
170	Lite Bossa			
171	Latin Rock			
172	Beguine 3			
173	Slow Bolero			
174	Disco Samba			
175	Mambo			
176	Meneito			
177	Rumba 2			
178	Rumba 3			
179	Tikitikita			
180	Lambada			
181	Pop Cha Cha 1			
	TZ&TRADITIONAL			
182	Waltz			
183	Old Waltz			
184	English Waltz			
185	German Waltz			
186	Italian Mazurka			
187	Mexico Waltz			
188	Vienna Waltz			
189	Slow Waltz 2			
190	Jazz Waltz			
191	Polka			
192	6/8 March			
193	German Polka			
194	Party Polka			
195	Army March			
196	March			
197	US March			
198	Musette			
199	French Musette			
200	Mazurka			
WOR	LD			
201	Enka Ballad			
202	Laendler			
203	Hawaiian			
204	Sirtake			
205	Dangdut			
206	6/8 Flipper			
207	New Age			
208	Tarantella			
209	Scottish			
210	Norteno			
PIAN				
211	Pianist 1			
212	Pianist 2			
213	Pianist 3			
214	March 1			
215	March 2			
216	Pop Waltz			
217	Slow Waltz			
218	Pop Bossa			
219	Jazz Pub			
<u> </u>	VALL I UD			

220	Jazz 1
221	Jazz 2
222	Piano Rock
223	Blues 1
224	Piano Beat
225	Piano Bar
226	Pop 1
227	Pop 2
228	Ballad 1
229	Ballad 2
230	6/8 Ballad











# **Song List**

No	Name	LCD Name
_	K & COUNTRY	
1	Toccata	Toccata
2	Carry Me Back To Old Virginny	Virginny
3	El Condor Pasa	ElCondor
4	Traumerei	Traumere
5	Aloha Oe	AlohaOe
6	Greensleeves	Sleeves
7	Home Sweet Home	SwetHome
8	Heidenroslein	Heidenro
9	Long Long Ago	LongAgo
10	Die Lorelei	Lorelei
11	Over The Waves	OverWave
12	My Darling Clementine	Clemtine
13	Gwine To Run All Night	Gwine
14	Symphony No.6 "Pathetic"	Sympony6
15	Oh! Susanna	Susanna
16	Prelude Op.28 No.15	Prelude
17	The House Of The Rising Sun	RiseSun
18	Menuet	Menuet
	LDEN & POP	Meridet
	Valse Des Fleurs	Fleurs
	Fruhlingsstimmen	Fruhling
21	Frohlicher Landmann	Landmann
22	Are You Lonesome Tonight?	Lonesome
23	Toy Symphony	ToySymph
24	Auld Lang Syne	LangSyne
25	Ave Maria	AveMaria
26	Tales Of Hoffman	Hoffman
27	La Donne Mobile	DoneMble
28	Serenata	Serenata
29	Bridal March	Bridal
30	Can't Help Fallin' In Love	InLove
31	Chanson Du Toreador	Toreador
32	Danny Boy	DannyBoy
33	Ich Liebe Dich	LieDich
34	Wiegenlied 2	Wieglid2
35	Spanish Serenade	Serenade
	Piano Concerto	Concerto
37	Piano Concerto 2	Concrto2
38	Madame Butterfly	Madame
39	Invitation To The Dance	ToDance
40	Wiegenlied 3	Wieglid3
41	Jingle Bells	JingBell
42	Joy To The World	JoyWorld
43	La Paloma	LaPaloma
44	My Bonnie	MyBonnie
45	La Reine De Saba	Saba
46	La Cucaracha	Cucarach
47	Little Brown Jug	BrownJug
48	Battle Hymne Of The Republic	BatlHyme
49	Yellow Rose Of Texas	YellRose
50	The Wabash Cannon Ball	CannBall
51	Annie Laurie	AnnieLa
52	Turkish March	Turkish
53	An Die Musik	Musik
54	Lieder Ohne Worte Op.62 No.6	Lieder
		1

		I =
	Red River Valley	RedRiver
56	Die Forelle	Forelle
57	Symphony No. 94 "Suprise"	No. 94
58	Polonaise	Polonais
59	Rondeau	Rondeau
60	Moments Musicaux	Musicaux
61	Silent Night	SltNight
62	Moldau	Moldau
63	Summertime	Summer
64	Dreaming Of Home And Mother	Dreaming
65	Ring Ring De Banjo	DeBanjo
66	Der Lindenbaum	DerLinde
67	Zigeunerweisen	Zigeuner
68	The Maiden's Prayer	Prayer
69	Fur Elise	FurElise
70	Der Freischutz	DerFreis
_	Maria! Mari!	Maria!
	ASSICAL	
	Waves Of The Danube	Danube
	Santa Lucia	SantaLuc
	Solveig's Song	Solveig
	Piano Sonatan No. 8 In C Minor (Pathetique)	Patheque
76	• • • • • • • • • • • • • • • • • • • •	· .
_	Brahms Waltz	BrmsWltz
77	Aida	Aida
78	Carmen-Prelude	Carmen
	L'Arlesienne	L'Arlesi
-	Uungarische Tanz	Uungaris
81	Mazurka	Mazurka
82	Pizzicato Polka	Polka
83	Menuett	Menuett
84	Rigoletto	Rigoleto
85	Serenade	Serenade
86	Song Without Words	SongNoWd
87	Swan	Swan
88	The Dying Swan	DyingSwn
89	Swan Lake Valse	SwnWalse
90	The Happy Farmer	HpFarmer
91	The Sleeping Beauty	SleepBty
92	La Traviata	LaTravia
93	Wiegenlied	Wiegenli
94	Mov. 2 Adagio Non Troppo Piano Sonata	Sonata9
	No. 9 In D	
95	Piano Sonata No. 11 In A	Sonata11
96	Prelude In C	Prelude
97	Chinese Dance	ChDance
98	Emperor Waltz	Emperor
99	March Militaire	Militair
100	Symphony No. 40	Symphony
PIA	<u> </u>	
101		Hanon1
_	Hanon Piano Fingering 2	Hanon2
	Hanon Piano Fingering 3	Hanon3
	Hanon Piano Fingering 4	Hanon4
	Hanon Piano Fingering 4  Hanon Piano Fingering 5	Hanon5
	Basic Tutorial Beyer Piano 12	Beyer12
107	•	Beyer13
108	Basic Tutorial Beyer Piano 14	Beyer14















## Song List

109	Basic Tutorial Beyer Piano 15	Beyer15
110	Basic Tutorial Beyer Piano 18	Beyer18
111	Cuckoo	Cuckoo
112	Basic Tutorial Beyer Piano 21	Beyer21
113	Basic Tutorial Beyer Piano 29	Beyer29
114	Butterfly	Buterfly
115	Basic Tutorial Beyer Piano 45	Beyer45
116	Christmas Eve	XmasEve
117	Basic Tutorial Beyer Piano 50	Beyer50
118	Basic Tutorial Beyer Piano 52	Beyer52
119	Basic Tutorial Beyer Piano 55	Beyer55
120	Basic Tutorial Beyer Piano 59	Beyer59
DEI	MO	
1	Demo1	Demo1
2	Demo2	Demo2
3	Bossa Nova	Bossa Nova
4	Fusion	Fusion
5	Jazz	Jazz















## **Chord List**

Chord name [abbreviation]	Normal Voicing (For root C)	Chord	Display
Major [M]	1+3+5	С	С
Sixth [6]	1+(3)+5+6	C6	C6
Major seventh [M7]	1+3+(5)+7	CM7	CM7
Major seventh add sharp eleventh [M7(#11)]	1+(2)+3+#4+(5)+7	CM7(#11)	CM7(#11)
Major seventh add sharp eleventh (9)]	1+2+3+5	C(9)	CM(9)
Major seventh ninth [M7(9)]	1+2+3+(5)+7	CM7(9)	CM7(9)
Sixth ninth [6(9)]	1+2+3+(5)+6	C6(9)	C6(9)
Augmented [aug]	1+3+#5	Caug	Caug
Minor [m]	1+b3+5	Cm	Cm
Minor sixth [m6]	1+b3+5+6	Cm6	Cm6
Minor seventh [m7]	1+b3+(5)+b7	Cm7	Cm7
Minor seventh flatted fifth [m7b5]	1+b3+b5+b7	Cm7b5	Cm7(b5)
Minor add ninth [m(9)]	1+2+b3+5	Cm(9)	Cm(9)
Minor seventh ninth [m7(9)]	1+2+b3+(5)+b7	Cm7(9)	Cm7(9)
Minor seventh eleventh [m7(11)]	1+(2)+b3+4+5+(b7)	Cm7(11)	Cm7(11)
Minor major seventh [mM7]	1+b3+(5)+7	CmM7	CmM7
Minor major seventh ninth [mM7(9)]	1+2+b3+(5)+7	CmM7(9)	CmM7(9)
Diminished [dim]	1+b3+b5	Cdim	Cdim
Diminished seventh [dim7]	1+b3+b5+6	Cdim7	Cdim7
Seventh [7]	1+3+(5)+b7	C7	C7
Seventh suspended fourth [7sus4]	1+4+5+b7	C7sus4	C7sus4
Seventh flatted fifth [7b5]	1+3+b5+b7	C7b5	C7(b5)
Seventh ninth [7(9)]	1+2+3+(5)+b7	C7(9)	C7(9)
Seventh add sharp eleventh [7(#11)]	1+2+3+#4+(5)+b7 or 1+(2)+3+#4+5+b7	C7(#11)	C7(#11)
Seventh add thirteenth [7(13)]	1+ 3+(5)+6+b7 or 2+ 3+5+6+b7	C7(13)	C7(13)
Seventh flatted ninth [7(b9)]	1+b2+3+(5)+b7	C7(b9)	C7(b9)
Seventh add flatted thirteenth [7(b13)]	1+3+5+b6+b7	C7(b13)	C7(b13)
Seventh sharp ninth [7(#9)]	(1)+#2+3+(5)+b7	C7(#9)	C7(#9)
Major seventh augmented [M7aug]	1+3+#5+7	CM7aug	CM7aug
Seventh augmented [7aug]	(1)+3+#5+b7	C7aug	C7aug
Suspended fourth [sus4]	1+4+5	Csus4	Csus4
One plus two plus five [sus2]	1+2+5	C/Csus2	С











## **MIDI** Implementation Chart

<b>Function</b>		Transmitted	Recognized	Remarks
Basic	Default	1ch	ALL	
Channel	Changed	1-16ch	1-16ch	
	Default	×	3	
Mode	Messages	×	3	
	Altered	******	×	
Note	Note	0—127	0—127	
Number	:True voice	******	0—127	
Velocity	Note on	○ 9nH,V=1 <b>-</b> 127	○ 9nH,V=1-127	
•	Note off	× (9nH,V=0)	○(9nH,V=0; 8nH,V=0-127)	
After	key's	×	×	
Touch	Ch's	×	×	
Pitch Bend		0	0	
Control	0	0	0	Bank Select
Change	1	×	0	Modulation
3	5	×	0	Portamento Time
	6	0	0	Data Entry
	7	0	0	Volume
	10	×	0	Pan
	11	×	0	Expression
	64	0	0	Sustain Pedal
	65	×	0	Portamento ON/OFF
	66	0	0	Sostenuto Pedal
	67	0	0	Soft Pedal
	80	×	0	Reverb Program
	81	×	0	Chorus Program
	91	0	0	Reverb Level
	93	0	0	Chorus Level
	120	×	0	All Sound Off
	121	×	0	Reset All Controllers
	123	×	0	All Notes Off
Program		0	0	7111140103 011
Change	:true	******	0-127	
System Exc		×	0 121	
System	:SongPosition	×	×	
Common	:Song Select	×	×	
3011111011	:Tune	×	×	
System	:Clock	×	×	
Real Time	:Commands	×*1	×	
Aux	:LOCAL ON/OFF	×	×	
Messages	:Active sense	×	0	
		ı "	1	

When the accompaniment is started, an FAH message is transmitted. When accompaniment is stopped, an FCH message is transmitted.

• Mode 1: OMNI ON, POLY

• Mode 2: OMNI ON, MONO

• Mode 3: OMNI OFF, POLY

o: YES

• Mode 4: OMNI OFF, MONO

×: NO

















A tuning system is the system used to define which tones, or pitches, to use when playing music. In other words, it is the choice of number and spacing of frequency values used. The equal temperament (has only one tuning method, and is suitable for keyboard) is the common musical scale used at present, used for the tuning of pianos and other instruments of relatively fixed scale. One of the advantages of the equal tempered scale is that it is the same in any musical "key", so that compositions may be freely transposed up or down without changing the musical intervals.

Especially for piano, equal temperament is widely used and taken for granted. But people used several other scales to compose and perform before adopting the equal temperament. This piano has been equipped with 6 scale tuning systems, you can select one to reappearing its matched chord of the melody at that time.

#### **Characteristics of Different Scale Tuning Systems**

#### **Pythagorean**

The Pythagorean tuning, named after the ancient mathematician and philosopher Pythagoras, is based on a stack of intervals called perfect fifths. It is particularly well suited to music which treats fifths as consonances, and thirds as dissonances.

#### **Pure Major & Pure Minor**

In music, just intonation (sometimes abbreviated as JI) or pure intonation is any musical tuning in which the frequencies of notes are related by ratios of small whole numbers. Any interval tuned in this way is called a pure or just interval. And the major scale which consisted of just intonations especially for this triad chords: Root, Third, Fifth are sounded extremely harmony. The just intonation must be the most natural temperament.

#### Meantone

The Meantone System is a musical temperament which is close to just intonation. Used to tuning pipe organ in 16th century Europe. These musical scales which based on the Pythagorean System, minus quarter of common comma for once, are extremely approaching just intonation. So, use this system to create musical scales are sound beautiful and pure, just like a perfect triad chord.

#### Werckmeister

The Werkmeister was named after Andreas Werckmeister, and this scale was created as an improvement on the Pythagorean scale. This tuning collapse comma maxima, created by Pythagorean, into four perfect fifths, the rest fifths still remain their Pythagorean scale characteristics. Werkmeister Tuning can tune scale from harmonic to melodic by increasing tone number, making each tonality sound distinct, this is the important gist for classicists and romanticism tonality music to name the tone name.

#### Kirnberger

Kirnberger temperament is an irregular temperament developed in the second half of the 18th century by Johann Kirnberger and regarded as an improved version of Meantone temperament. It makes possible to switch different tunes freely when performing.

#### Twelve-tone equal temperament

In twelve-tone equal temperament, which divides the octave into 12 equal parts, the width of a semitone, i.e. the frequency ratio of the interval between two adjacent notes, is the twelfth root of two. There is minute difference of the same amount between each two intervals.













