AW_DD630_Setup manual_G01_180323.pdf 1 2018/3/23 11:50:03

Setup Manual

WARNING
- Drum key can be pinched when adjusting clamps with drum key. Operate carefully.
- Be careful around pipe ends, inside the pipe, screw ends and metal shavings...etc. May injure your fingers

Check the included items

CYMBAL PAD



Hi-hat | Crash | Ride

DRUM PAD



Tom (x 3) | Snare

KICK (PAD + PEDAL)



Kick Pad | Kick Pedal | Beater

PEDAL



Pedal (Hi-hat)

MODULE



Drum Module | Connection Cable

DRUM STAND



Pillar **[A]** | Pillar **[B]** | Pillar **[C]** | Pillar **[D]**
Pipe **[E]** x 3 | Pipe **[F]** | Pipe **[G]**
Cymbal Holder x 2 | Hi-hat Holder

ACCESSORIES



L-Rod Holder | Cable Clip | Drum Key
Drumsticks | Hand bolt
Owner's Manual | Setup Manual (This document) | AC Adaptor

Attach the Tom Pads



Assemble the Drum Stand



Attach the Pad, Hi-hat and Cymbal Holders



AW_DD630_Setup manual_G01_180323.pdf 2 2018/3/23 11:50:04

Attach the Drum Pad (Snare)



Attach the Cymbal Pad





Attach the Drum Module



Attach the Kick Pad



When using a twin pedal
Position the two beaters equally apart from the center of the kick pad.

Connect the Pads



Connect the Pads to the Drum Module with labelled cables.

DD630_G01