

Setup Guide


WARNING:


- Drum key can be pinched when adjusting clamps with drum key. Operate carefully.
 Be careful around pipe ends, inside the pipe and screw ends. Metal shavings, etc. May injure your fingers.


Check the include items
















Attach the Pads

- 1.Loosen wing nut on the holder clamp, which is on the center pipe(1), side arm(L2) and side arm(R).
- 2.Attach drum pads to the holder clamp on center pipe(1),side arm(L2),side arm(R) and tighten wing nuts. Repeat for each pad.



Attach the Cymbal Pads

- 1. Remove the wing nut and felt washer from the cymbal tilter.
- Place the cymbal pad, felt washer, wing nut 3 assembly as shown, and tighten the wing nut 3 to obtain an appropriate amount of sway.
- 3. Adjust the cymbal pad position with the wing nut 4.




Assemble the Kick

- 1. Insert the beater to the beater holder on the foot pedal.
- 2. Adjust the beater position and tighten the beater with the drum key.
- 3. Attach the foot pedal to the kick pad.
- 4. Adjust the beat position and tighten the wing nut.

Note:

Position the one beater in the center of the kick pad kick.




Connect the Pads to the Drum Module

Attach the Drum Module

- Connect the cable to the drum module as shown with hands crews.
- 2. Attach the drum module to the mount holders on Side Arm (L1), and firmly tighten the relevant wing nut.

Note

Adjust the drum module position by moving the mount holders as needed, and firmly tighten the relevant wing nut.



Connection Procedure

- 1. Place the kick on the floor in the center of the rack as shown.
- 2. Place the hi-hat pedal on the floor on your left side.
- Connect the pads to the drum module with the marked cables

Are you ready? Let's enjoy playing it.

