

# **Setup Guide**


### **WARNING:**


- Drum key can be pinched when adjusting clamps with drum key. Operate carefully.
- Be careful around pipe ends, inside the pipe and screw ends. Metal shavings, etc. May injure your fingers.


# Check the include items





















- 1. Attach the Center Pipe (1) to the clamp on the Pillar (L1).
- 2. Attach the Center Pipe (2) to the clamp on the Pillar (L1).
- 3. Attach the Center Pipe (1) & (2) to the clamps on the Pillar (R1).
- 4. Attach the Side Arm (L1) to the clamp on the Pillar (L2).
- 5. Attach the Side Arm (L1) to the clamp on the Pillar (L1).
- 6. Attach the Side Arm (R) to the clamp on the Pillar (R2).
- 7. Attach the Side Arm (R) to the clamp on the Pillar (R1).
- 8. Attach the Side Arm (L2) to the clamp on the Pillar (L1).

### Note:


- Loosen or tighten the screws on the clamp with drum key as shown partial enlargement.
- Adjust the height of the Side Arms with drum key as needed.



 Attach the pad mounts to the mount holders on the Center Pipe (1), Side Arm (L2), Side Arm (R), and firmly tighten the respective wing nuts 1.

### Note:

- Loosen or tighten the wing nuts on the mount holder as shown partial enlargement.
- Move the mount holders as needed, and firmly tighten the respective wing nuts 2.



10. Insert the two cymbal holders into the holders on the Pillars, attach the hi-hat holder to mount holders on the Side Arm (L1), and firmly tighten the respective wing nuts.

### Note:

Loosen or tighten the wing nuts on the mount holder as shown partial enlargement.

# 1. Loosen the wing nut 3 on the drum pad. 2. Attach the drum pad to the pad mount, and firmly tighten the wing nut 3 on the drum pad. 3. Loosen the wing nut 4 on the drum pad. 4. Attach the drum pad to the pad mount, and firmly tighten the wing nut 4 on the drum pad. Wing Nut 4 Wing Nut 4


### **Attach the Cymbal Pads** Cymbal Holder (L) Cymbal Holder (R) Cymbal Holder (L) 1. Remove the wing nut 5 and felt Cymbal Holder (R) washer from the cymbal tilter. Move Out ▲ Wing Nut 5 2. Place the cymbal pad, felt Felt Washer washer, wing nut 5 assembly as Wing Nut 6 Wing Nut 6 shown, and tighten the wing nut 5 to obtain an appropriate amount of sway. Adjust the cymbal pad position Cymbal Holder (S) with the wing nut 6. Slot ₩ing Nut 5 Note: = Felt Washer Ride ■ Put the cymbal on the cymbal Move Out adapter and locate the tap of Wing Nut 6 the adapter in the slot of the Wing Nut 6 cymbal bottom. ■ Tighten the bolt with the Hi-Hat Holder hexagon key (1) as shown partial enlargement

# Assemble the Kick

- 1. Insert the beater to the beater holder on the foot pedal.
- 2. Adjust the beater position and tighten the beater with the drum key.
- 3. Attach the foot pedal to the kick pad.
- 4. Adjust the beat position and tighten the wing nut.

### Note:

Position the one beater in the center of the kick pad or the two beaters equally apart from the center of the kick pad as shown.




# **Connect the Pads to the Drum Module**

# **Attach the Drum Module**


- 1. Push the cable into the mount holder slot on Side Arm(L1) as shown.
- 2. Connect cable to the DB25 Jack on the back of drum module.
- 3. Attach the module to the mount holder on the side Arm (L1), and firmly tighten with the screws.

### Note:

Adjust the drum module position by moving the mount holders as needed, and firmly tighten the relevant wing nut.



# **Connection Procedure**



- 1. Place the kick on the floor in the center of the rack as shown.
- 2. Place the hi-hat pedal on the floor on your left side.
- 3. Connect the pads to the drum module with the marked cables.

Are you ready? Let's enjoy playing it.

